

Federal Aviation Administration

# Aeronautical Information Services Aeronautical Chart Users' Guide

Effective as of 17 April 2025

# TABLE OF CONTENTS

TABLE OF CONTENTS	3
INTRODUCTION	7
KEEP YOUR CHARTS CURRENT	
EFFECTIVE DATE OF CHART USERS' GUIDE AND UPDATES	
COLOR VARIATION	
REPORTING CHART DISCREPANCIES	
WHAT'S NEW?	9
VFR CHARTS	9
IFR ENROUTE CHARTS	9
TERMINAL PROCEDURE PUBLICATION (TPP)	9
EXPLANATION OF VFR TERMS AND SYMBOLS	11
WATER FEATURES (HYDROGRAPHY)	11
LAND FEATURES (TERRAIN) AND OBSTRUCTIONS	11
LAND FEATURES - MOUNTAIN PASSES	14
RADIO AIDS TO NAVIGATION	
AIRPORTS	
AIRSPACE	
FOREIGN AREAS	
TERMINAL AREA CHART (TAC) COVERAGE	
INSET AND SPECIAL CHART COVERAGE	
CHART TABULATIONS	
VFR SECTIONAL AND TERMINAL AREA CHARTS	
RADIO AIDS TO NAVIGATION	
AIRSPACE INFORMATION NAVIGATIONAL AND PROCEDURAL INFORMATION	
CULTURE	
HYDROGRAPHY	
RELIEF	
VFR FLYWAY PLANNING CHARTS	43
GENERAL INFORMATION	43
AIRPORTS	
RADIO AIDS TO NAVIGATION	
AIRSPACE INFORMATION	
NAVIGATIONAL AND PROCEDURAL INFORMATION	
BOUNDARIES	
HYDROGRAPHY	
RELIEF	48

# TABLE OF CONTENTS

HELICOPTER ROUTE CHARTS	19
GENERAL INFORMATION	
AIRPORTS	
RADIO AIDS TO NAVIGATION	
AIRSPACE INFORMATION	
NAVIGATIONAL AND PROCEDURAL INFORMATION	
CULTURE	
CARIBBEAN VFR AERONAUTICAL CHARTS (CAC)	. 57
AIRSPACE	. 59
EVEL ANATION OF ICE ENDOUTE TERMO	04
EXPLANATION OF IFR ENROUTE TERMS	-
	-
RADIO AIDS TO NAVIGATION	
AIRSPACE INFORMATION	
INSTRUMENT AIRWAYS	
FOREIGN AREAS	
TERRAIN CONTOURS ON AREA CHARTS	
AIRPORTS	73
CHARTS) RADIO AIDS TO NAVIGATION AIRSPACE INFORMATION NAVIGATIONAL AND PROCEDURAL INFORMATION CULTURE	74 79 92 93
HYDROGRAPHY	93
TOPOGRAPHY	93
	05
U.S. TERMINAL PROCEDURES PUBLICATION EXPLANATION OF TPP TERMS AND SYMBOLS	
INSTRUMENT APPROACH PROCEDURE CHART	
PLANVIEW	
MISSED APPROACH INFORMATION	
PROFILE VIEW	
LANDING MINIMUMS	
AIRPORT SKETCH	
AIRPORT DIAGRAMS	
DEPARTURE PROCEDURES (DPs)	123
STANDARD TERMINAL ARRIVAL (STARs) CHARTS	124
CHARTED VISUAL FLIGHT PROCEDURE (CVFP) CHARTS	124
U.S. TERMINAL PROCEDURES PUBLICATION SYMBOLS	
GENERAL INFORMATION	
PLANVIEW SYMBOLS	125

# TABLE OF CONTENTS

PROFILE VIEW	127
STANDARD TERMINAL ARRIVAL (STAR) CHARTS	128
DEPARTURE PROCEDURE (DP) CHARTS	129
AIRPORT DIAGRAM/AIRPORT SKETCH	130
APPROACH LIGHTING SYSTEM	131
REFERENCES	
ABBREVIATIONS	135

FAA Chart Users' Guide - Table of Contents

# INTRODUCTION

This Chart Users' Guide is an introduction to the Federal Aviation Administration's (FAA) aeronautical charts and publications. It is useful to new pilots as a learning aid, and to experienced pilots as a quick reference guide.

The FAA is the source for all data and information utilized in the publishing of aeronautical charts through authorized publishers for each stage of Visual Flight Rules (VFR) and Instrument Flight Rules (IFR) air navigation including training, planning, departures, enroute (for low and high altitudes), approaches, and taxiing charts. Digital charts are available online at:

- VFR Charts
- IFR Charts
- <u>Terminal Procedures Publication</u>
- <u>Chart Supplements</u>

Paper copies of the charts are available through an FAA Approved Print Provider. A complete list of current providers is available at <a href="http://www.faa.gov/air\_traffic/flight\_info/aeronav/print\_providers/">http://www.faa.gov/air\_traffic/flight\_info/aeronav/print\_providers/</a>.

The FAA Aeronautical Information Manual (AIM) Pilot/Controller Glossary defines all terms and abbreviations used throughout this publication. Unless otherwise indicated, miles are nautical miles (NM), altitudes indicate feet above Mean Sea Level (MSL), and times used are Coordinated Universal Time (UTC).

Notices to Airmen (NOTAMs) alert pilots to time-critical aeronautical information that is either temporary or not sufficiently known in advance to permit publication on aeronautical charts or in other operational publications. Pilots can access NOTAM information via Flight Service Stations (FSS) or online via NOTAM Search at <a href="https://notams.aim.faa.gov/notam-search/">https://notams.aim.faa.gov/notam-search/</a>.

In addition to NOTAMs, the Safety Alerts/Charting Notices page of the Aeronautical Information Services website is also useful to pilots.

# **KEEP YOUR CHARTS CURRENT**

Aeronautical information changes rapidly, so it is important that pilots check the effective dates on each aeronautical chart and publication. To avoid danger, it is important to always use current editions and discard obsolete charts and publications.

To confirm that a chart or publication is current, refer to the next scheduled edition date printed on the cover. Pilots should also check NOTAMs for important updates between chart and publication cycles that are essential for safe flight.

# EFFECTIVE DATE OF CHART USERS' GUIDE AND UPDATES

All information in this guide is effective as of **17 April 2025**. All graphics used in this guide are for educational purposes. Chart symbology may not be to scale. Please do not use them for flight navigation.

The Chart Users' Guide is published in accordance with the 56-day aeronautical chart product schedule.

# **COLOR VARIATION**

Although the digital files are compiled in accordance with charting specifications, the final product may vary slightly in appearance due to differences in printing techniques/processes and/or digital display techniques.

# **REPORTING CHART DISCREPANCIES**

Your experience as a pilot is valuable and your feedback is important. We make every effort to display accurate information on all FAA charts and publications, so we appreciate your input. Please notify us concerning any requests for changes, or potential discrepancies you see while using our charts and related products.

> FAA, Aeronautical Information Services 1305 East-West Highway SSMC4, Room 3424 Silver Spring, MD 20910-3281

Telephone Toll-Free 1-800-638-8972 Aeronautical Inquires: <u>https://www.faa.gov/air\_traf-</u> fic/flight\_info/aeronav/aero\_data/Aeronautical\_In-<u>quiries/</u> FAA Chart Users' Guide - Introduction

# WHAT'S NEW?

Update as of 17 April 2025

The following charting items have been added to the Chart Users' Guide since the Guide was last published on 20 February 2024:

# **VFR CHARTS**

No Significant Changes Applied

# **IFR ENROUTE CHARTS**

No Significant Changes Applied

# **TERMINAL PROCEDURE PUBLICATION (TPP)**

No Significant Changes Applied

FAA Chart Users' Guide - What's New

# **EXPLANATION OF VFR TERMS AND SYMBOLS**

This chapter covers the Sectional Aeronautical Chart (Sectional). These charts include the most current data at a scale of (1:500,000), which is large enough to be read easily by pilots flying by sight under Visual Flight Rules. Sectionals are named after a major city within its area of coverage.

The chart legend includes aeronautical symbols and information about drainage, terrain, the contour of the land, and elevation. You can learn to identify aeronautical, topographical, and obstruction symbols (such as radio and television towers) by using the legend.

A brief description next to a small black square indicates the exact location for many of the landmarks easily recognized from the air, such as stadiums, pumping stations, refineries, etc. A small black open circle with descriptive type indicates oil, gas or mineral wells. A small black circle with descriptive type indicates water, oil or gas tanks. The scale for some items may be increased to make them easier to read on the chart.

Aeronautical Information Services' charts are prepared in accordance with specifications of the Interagency Air Committee (IAC) and are approved by representatives of the Federal Aviation Administration (FAA) and the Department of Defense (DoD).

# WATER FEATURES (HYDROGRAPHY)



Water features are depicted using two tones of blue, and are considered either "Open Water" or "Inland Water." "Open Water," a lighter blue tone, shows the shoreline limitations of all coastal water features at the average (mean) high water levels for oceans and seas. Light blue also represents the connecting waters like bays, gulfs, sounds and large estuaries.

Exceptionally large lakes like the Great Lakes, Great Salt Lake, and Lake Okeechobee, etc., are considered Open Water features. The Open Water tone extends inland as far as necessary to adjoin the darker blue "Inland Water" tones. All other bodies of water are marked as "Inland Water" in the darker blue tone.

# LAND FEATURES (TERRAIN) AND OBSTRUCTIONS

The elevation and configuration of the Earth's surface is important to pilots. Our Aeronautical Information Specialists are devoted to showing the contour of the earth and any obstructions clearly and accurately on our charts. We use five different techniques: contour lines, shaded relief, color tints, obstruction symbols, and Maximum Elevation Figures (MEF).

 Contour lines join points of equal elevation. On Sectionals, basic contours are spaced at 500' intervals. Intermediate contours are typically at 250' intervals in moderately level or gently rolling areas. Auxiliary contours at 50', 100', 125', or 150' intervals occasionally show smaller relief features in areas of relatively low relief. The pattern of these lines and their appairing gives the pilot a visual segment of the terrain. Widely appaged contours are set their appairing gives the pilot a visual segment of the terrain.

and their spacing gives the pilot a visual concept of the terrain. Widely spaced contours represent gentle slopes, while closely spaced contours represent steep slopes.

2. Shaded relief shows how terrain may appear from the air. Shadows are shown as if light is coming from the northwest, because studies have shown that our visual perception has been conditioned to this view.



- Different color tints show bands of elevation relative to sea level. These colors range from light green 3 19633 for the lower elevations, to dark brown for the higher elevations.
- GLACIER Obstruction symbols show man made vertical features that could affect safe navigation. The FAA maintains a database of obstacles. Aeronautical Specialists evaluate each obstacle based on charting specifications before adding it to a a visual chart. When a Specialist is not able 12000 to verify the position or elevation of an obstacle, it is marked UC, meaning it is "under construction" or being reported, but has not been verified. 9000 The FAA uses a Digital Obstacle File (DOF) to collect and disseminate data. Because land and obstructions frequently change, the source data on obstructions and terrain is occasionally incomplete or not accurate 7000 enough for use in aeronautical publications. For example, when the FAA receives notification about an obstruction, and there is insufficient detail to determine its position and elevation, the FAA Flight Edit Program conducts an investigation. 5000 -The Flight Edit crew visually verifies the cultural, topographic, and obstacle data. Charts are generally flight-3000 checked every four years. This review includes checking for any obstruction that has been recently built, altered, or dismantled without proper notification. 2000 Sectional Charts and Terminal Area (TACs) typically show man-made obstacles extending more than 200' Above Ground Level (AGL), or more than 299' AGL in yellow 1000 city tint. Obstacles may be lit or unlit. Features considered to be hazardous obstacles to low-level flight are; smokestacks, tanks, factories, lookout towers, antennas, and Sea Level wind turbines, etc. -228

Man-made features used by FAA Air Traffic Control as checkpoints use a graphic symbol shown in black with the required elevation data in blue. The elevation of the top of the obstacle above Mean Sea Level (MSL) and the height of the structure (AGL) is also indicated (when known or can be reliably determined by a Specialist). The AGL height is in parentheses below the MSL elevation. In extremely congested areas, the GARFIELD FAA typically omits the AGL values to avoid confusion.



**Obstacles less than** 

Obstacles 1000'AGL

1000'AGL.

or greater.

Wind Turbines.

5540

(650)

STACK

Ŵ

4.

Whenever possible, the FAA depicts specific obstacles on charts. However, in high-density areas like city complexes, only the highest obstacle is represented on the chart using the group obstacle symbol to maximize legibility.

5000 (1500) UC

If space is available the AGL height of the obstruction is shown in parentheses.

솠 Guv wires may extend outward

from obstacles.

Wind turbines with high intensity lighting.

Obstacles with high-intensity strobe lighting systems may operate part-time or by proximity activation and are shown as follows:

Obstacles under construction are indicated by placing the letters UC adjacent to the obstacle type.



Concentrated obstructions of wind turbine farms shall be portrayed by an overlying hatched area and dotted outline to represent the approximate parameters of the farm. One or more single turbine symbols will populate the farm. A boxed elevation figure representing the MSL elevation of the highest wind turbine within the area shall be placed inside the farm or, if space is limited, just outside. Pilots are reminded that wind turbine blades and/or blade tips are not lighted. Wind turbine obstruction lights are located on top of the nacelle (generator) at the hub of wind turbines, which in some cases can be 200-300' below the rotating blade tips.

5. The Maximum Elevation Figure (MEF) represents the highest elevation within a quadrant, including terrain and other vertical obstacles (towers, trees, etc.). A quadrant on Sectionals is the area bounded by ticked lines dividing each 30 minutes of latitude and each 30 minutes of longitude. MEF figures are rounded up to the nearest 100' value and the last two digits of the number are not shown.



MEFs over land and open water areas are used in areas containing man-made obstacles such as oil rigs.

In the determination of MEFs, the FAA uses extreme care to calculate the values based on the existing elevation data shown on source material. Aeronautical Information Specialists use the following procedure to calculate MEFs:

#### **MEF - Man-made Obstacle**

When a man-made obstacle is more than 200' above the highest terrain within the quadrant:

- 1. Determine the elevation of the top of the obstacle above MSL.
- Add the possible vertical error of the source material to the above figure (100' or 1/2 contour interval when interval on source exceeds 200'. U.S. Geological Survey Quadrangle Maps with contour intervals as small as 10' are normally used).
- 3. Round the resultant figure up to the next higher hundred-foot level.

#### Example:

Elevation of obstacle top (MSL)	2649
Possible obstacle error	+100
equals	2749
Raise to the following 100' level	2800
Maximum Elevation Figure (MEF)	28



## MEF - Natural Terrain Feature or Natural Vertical Obstacle

When a natural terrain feature or natural vertical obstacle (e.g. a tree) is the highest feature within the quadrangle:

- 1. Determine the elevation of the feature.
- 2. Add the possible vertical error of the source to the above figure (100' or 1/2 the contour interval when interval on source exceeds 200').
- Add a 200' allowance for uncharted natural or manmade obstacles. Chart specifications don't require the portrayal of obstacles below minimum height.
- 4. Round the figure up to the next higher hundredfoot level.

# Example:

Elevation of obstacle top (MSL)	13161
Possible vertical error	+100
Obstacle Allowance	+200
equals	13461
Raise to the following 100' level	13500
Maximum Elevation Figure (MEF)	135



Pilots should be aware that while the MEF is based on the best information available to the Specialist, the figures are not verified by field surveys. Also, users should consult the Aeronautical Information Services website to ensure that your chart has the latest MEF data available.

# LAND FEATURES - MOUNTAIN PASSES

The Mountain Pass symbol does not indicate a recommended route or direction of flight, and pass elevation does not indicate a recommended clearance altitude. Hazardous flight conditions may exist within and near mountain passes. For high-traffic mountain passes, VFR Checkpoints may be provided to increase situational awareness by indicating key landmarks inside confined terrain. A collocated VFR Waypoint and Checkpoint may be provided to assist with identifying natural entry points for commonly flown mountain passes.



# **RADIO AIDS TO NAVIGATION**

On VFR Charts, information about radio aids to navigation (NAVAID) are boxed, as illustrated. Duplication of data is

avoided. When two or more radio aids in a general area have the same name with different frequencies, Tactical Air Navigation (TACAN) channel numbers, or identification letters, and no misinterpretation can result, the name of the radio aid may be indicated only once within the identification box. Very High Frequency/Ultra High Frequency (VHF/UHF) NAVAID names and identification boxes (shown in blue) take precedence. Only



114.3 SVM 🔛

t. Type of NAVAID n in top of box.

those items that differ (e.g., frequency, Morse Code) are repeated in the box in the appropriate color. The choice of separate or combined boxes is made in each case on the basis of economy of space and clear identification of the radio aids.

A NAVAID that is physically located on an airport may not always be represented as a typical NAVAID symbol. A small open circle indicates the NAVAID location when collocated with an airport icon.

The type of NAVAID will be identified by: "VOR," (VHF Omni-Directional Range) "VORTAC" (VOR Tactical Aircraft Control), "VOR-DME," (VOR-Distance Measuring Equipment) or "DME" (Distance Measuring Equipment) positioned on and breaking the top line of the NAVAID box.

DMEs are shown without the compass rose.

# AIRPORTS

Airports in the following categories are charted as indicated (additional symbols are shown later in this Section). Public use airports:

Hard-surfaced runways greater than 8069' or some multiple runways less than 8069'

- Hard-surfaced runways 1500' to 8069'
- Other than hard-surfaced runways
- 🖞 Seaplane bases

Military airports:



Other than hard-surfaced runways

Foreign airports:

Ο

Hard-surfaced runways are depicted the same as public-use airports.

U.S. military airports are identified by abbreviations such as AAF (Army Air Field), AFB (Air Force Base), MCAS (Marine Corps Air Station), NAS (Naval Air Station), NAV (Naval Air Facility), and NAAS (Naval Auxiliary Air Station).

Fuel Available:



Fuel availability indicated by use of tick marks around the basic airport symbol. Consult Chart Supplement for details and availability.

Airports are plotted in their true geographic position unless the symbol conflicts with a NAVAID at the same location. In such cases, the airport symbol will be displaced, but the relationship between the airport and the NAVAID will be retained. When a waypoint is collocated with a towered airport, the waypoint symbol will not be charted and the waypoint name followed by (WP) will be shown leadered to the waypoint true location. When depicting a seaplane base, the eye of the anchor symbol will be charted as close to the docking area as possible, with the remainder of the symbol in the water.

Airports are identified by their official FAA designated name.

The elevation of an airport is the highest point on the usable portion of the landing areas. Runway length is the length of the longest active runway, including displaced thresholds and excluding overruns. Runway length is shown to the nearest 100', using 70 as the rounding point; a runway 8070' in length is charted as 81, while a runway 8069' in length is charted as 80. If an airport has waterways, it will be indicated by a seaplane base symbol and additional elevation, lighting, and length information under primary airport information.



Flight Service Station on field	FSS	Elevation in feet	285
Airports where fixed wing special VFR operations are prohibited (shown above airport name) FAR 91	NO SVFR	Lighting in operation Sunset to Sunrise	L
Indicates FAR 93 Special Air Traffic Rules and Airport Traffic Pattern		Lighting limitations exist; refer to Chart Supple- ment	*ل
Location Identifier	(NAM)	Length of longest runway in hundreds of feet; usable length may be less	72
ICAO Location Identifier	(PNAM)	Aeronautical advisory station	122.95
Control Tower (CT) - primary frequency	ст - <b>118.3</b>	Runways with Right Traffic Patterns (public use)	RP 23,34
Star indicates operation part-time. See tower frequencies tabulation for hours of operation	*	See Chart Supplement	*RP
Follows the Common Traffic Advisory Frequency (CTAF)	0	VFR Advisory Service Shown when ATIS is not available and frequency is other than the primary CT frequency	VFR Advsy <b>125.0</b>
Automatic Terminal Information Services	ATIS 123.8	Weather Camera (Alaska)	WX CAM
Automatic Flight Information Service	AFIS 135.2	Airport of Entry	AOE
Automated Surface Weather Observing Systems; shown when full-time ATIS is not available	ASOS/AWOS 135.42	When information is lacking, the respective character is replaced by a dash. Lighting codes refer to runway edge lights and may not repre- sent the longest runway or full length lighting.	

Airports with Control Towers (CT) and their related data are shown in blue. All other airports and their related data are shown in magenta. The **L** symbol indicates that runway lights are on from dusk to dawn. \*L indicates that the pilot must consult the Chart Supplement to determine runway lighting limitations, such as: available on request (by radio-call, letter, phone, etc), part-time lighting, or pilot/airport controlled lighting. Lighting codes refer to runway edge lights. The lighted runway may not be the longest runway available, and lights may not be illuminated along the full length of the runway. The Chart Supplement has a detailed description of airport and air navigation lighting aids for each airport. A dash represents no runway edge lights.

20 NM ON 124.6 395.9

The symbol 🔆 indicates the existence of a rotating or flashing airport beacon operating from dusk to dawn. The Aeronautical Information Manual (AIM) thoroughly explains the types and uses of airport lighting aids.

Right traffic information is shown using the abbreviation 'RP' for right pattern, followed by the appropriate runway number(s) (RP 18). Special conditions or restrictions to the right pattern are indicated by the use of an asterisk (\*RP) to direct the pilot to the Chart Supplement for special instructions and/or restrictions.

The type "OBJECTIONABLE" associated with an airport symbol indicates that an objectionable airspace determination has been made for the airport per FAA JO 7400.2 Section 4, Airport Charting and Publication of Airport Data. Objectionable airspace determinations are based upon a number of factors including conflicting traffic patterns with another airport, hazardous runway conditions, or natural or man-made obstacles in close proximity to the landing area. FAA Regional Airports Offices are responsible for airspace determinations. Address any challenges to objectionable airspace determinations to your FAA Regional Airports Office.

# AIRSPACE

#### **CONTROLLED AIRSPACE**

Controlled airspace consists of those areas where some or all aircraft may be subject to air traffic control, such as: Class A, Class B, Class C, Class D, Class E Surface (SFC) and Class E Airspace.

**Class A Airspace** within the United States extends from 18,000' up to FL600. While visual charts do not depict Class A, it is important to note its existence.

**Class B Airspace** is shown on the Sectional Aeronautical Chart (Sectional) and Terminal Area Chart (TAC). Class B MSL 90 The MSL ceiling and floor altitudes of each sector are shown in solid blue figures with the last two zeros altitudes of each sector are shown in solid blue figures with the last two zeros altitudes are outside of Class B Airspace. Radials and arcs used to define Class B are prominently shown on TACs. Detailed rules and requirements associated with the particular Class B are shown. The name by which the Class B is shown as LAS VEGAS CLASS B for example.

Class C Airspace is shown on Sectionals and TACs. The MSL ceiling and floor altitudes of each sector are Class C MSL 70 shown in solid magenta figures with the last two zeros eliminated.

A ceiling value of "T" indicates the ceiling is to, but not including, the floor of the overlying Class B airspace. Surface.

Class C Airspace is identified by name: BURBANK CLASS C

Separate notes, enclosed in magenta boxes, give the approach control frequencies to be used by arriving VFR aircraft to establish two-way radio communication before entering the Class C (generally within 20 NM):

Class C operating less than continuous is indicated by the following note: See NOTAMS/Supplement for Class C eff hrs

Class D Airspace is identified with a blue dashed line. Class D operating less than continuous is indicated by the following note: See NOTAMs/Supplement for Class D eff hrs

Ceilings of Class D are shown as follows: 30

A minus in front of the figure is used to indicate "from surface to, but not including..."

Class E Surface (SFC) Airspace is symbolized with a magenta dashed line. Class E (SFC) operating less than continuous is indicated by the following note: See NOTAMS/Supplement for Class E (sfc) eff hrs

**Class E Airspace** exists at 1200' AGL unless designated otherwise. The lateral and vertical vertical limits of all Class E, (up to, but not including 18,000') are shown by narrow bands of vignette on Sectionals and TACs.

Controlled airspace floors of 700' above the ground are defined by a magenta vignette; floors other than 700' that laterally abut uncontrolled airspace (Class G) are defined by a blue vignette; differing floors greater than 700' above the ground are annotated by a symbol and a number indicating the floor. <sup>2400</sup> AGL

4500 MSL If the ceiling is less than 18,000' MSL, the value (preceded by the word "ceiling") is shown along the limits of the controlled airspace. These limits are shown with the same symbol indicated above.

# UNCONTROLLED AIRSPACE

**Class G Airspace** within the United States extends up to 14,500' Mean Sea Level. At and above this altitude is Class E, excluding the airspace less than 1500' above the terrain and certain special use airspace areas.

# SPECIAL USE AIRSPACE

**Special Use Airspace (SUA)** confines certain flight activities and restricts entry, or cautions other aircraft operating within specific boundaries. Except for Controlled Firing Areas, SUA areas are depicted on VFR Charts. Controlled Firing Areas are not charted because their activities are suspended immediately when spotter aircraft, radar, or ground lookout positions indicate an aircraft might be approaching the area. Nonparticipating aircraft are not required to change their flight paths. SUA areas are shown in their

entirety (within the limits of the chart), even when they overlap, adjoin, or when an area is designated within another area. The areas are identified by type and identifying name/number, and are positioned either within or immediately adjacent to the area.

\* Alert Areas do not extend into Class A, B, C and D airspace, or Class E airport surface areas.

# OTHER AIRSPACE AREAS

**Mode C Required Airspace** (from the surface to 10,000' MSL) within a 30 NM radius of the primary airport(s) for which a Class B is designated, is depicted by a solid magenta line.

Mode C is required, but not depicted for operations within and above all Class C up to 10,000' MSL.

Enroute Mode C requirements (at and above 10,000' MSL except in airspace at and below 2500' AGL) are not depicted. See FAR 91.215 and the AIM.

**FAR 93** Airports and heliports under Federal Aviation Regulation 93 (FAR 93), (Special Air Traffic Rules and Airport Traffic Patterns), are shown by "boxing" the airport name.

**FAR 91** Airports where fixed wing special visual flight rules operations are prohibited (FAR 91) are shown with the type "NO SVFR" above the airport name.

**The Washington DC Flight Restricted Zone (FRZ)** is related to National Security. It is depicted using the Prohibited/ Restricted/Warning Area symbology and is located within the SFRA. It is defined as the airspace within approximately a 13 to 15 NM radius of the DCA VOR-DME. Additional requirements are levied upon aviators requesting access to operate inside the National Capital Region.



VANCE 2 MOA

**TRUCKEE - TAHOE** 



**Temporary Flight Restriction (TFR) Areas Relating to National Security** are indicated with a broken blue line A Temporary Flight Restriction (TFR) is a type of Notice to Airmen (NOTAM). A TFR defines an area where air travel is restricted due to a hazardous condition, a special event, or a general warning for the entire airspace. The text of the actual TFR contains the fine points of the restriction. It is important to note that only TFRs relating to National Security are charted.

**Terminal Radar Service Areas (TRSAs)** are shown in their entirety, symbolized by a screened black outline of the entire area including the various sectors within the area

The outer limit of the entire Terminal Radar Service Areas (TRSA) is a continuous screened black line. The various sectors within the TRSA are symbolized by narrower screened black lines.

Each sector altitude is identified in solid black color by the MSL ceiling and floor values of the respective sector, eliminating the last two zeros. A leader line is used when the altitude values must be positioned outside the respective sectors because of charting space limitations. The TRSA name is shown near the north position of the TRSA as follows: **PALM SPRINGS TRSA**. Associated frequencies are listed in a table on the chart border.

The following note appears on Helicopters, Sectionals and TACs except for Hawaiian Islands, which is different.



## There are IFR (IR) and VFR (VR) routes as follows:

#### **Route identification:**

a. MTRs with no segment above 1500' are identified by four-digit numbers; e.g., VR1007, etc. These routes are generally developed to be flown under Visual Flight Rules.

b. MTRs that include one or more segments above 1500' AGL are identified by three or fewer digit numbers; e.g., IR21, etc. These routes are developed to be flown, to the maximum extent possible under Instrument Flight Rules.

Route width varies for each MTR and can extend several miles on either side of the charted MTR centerline. Detailed route width information is available in the Flight Information Publication (FLIP) AP/1B (a Department of Defense publication), or through the 56 Day NASR Subscription from the National Flight Data Center (NFDC).

**Special Military Activity** areas are indicated on Sectionals by an underlying IFR Military Training Route with the lateral limits of the route shown by a gray Special Use Airspace symbol. A boxed note accompanies the area. The note contains radio frequency and route identifier information to use for obtaining area activity status.

SPECIAL MILITARY ACTIVITY FOR IR850, IR851, IR852 CTC BANGOR RADIO ON 122.4 255.4 FOR ACTIVITY STATUS

The following guidance appears in the margin of applicable Sectional Charts.

#### SPECIAL MILITARY ACTIVITY

The chart identifies IFR Military Training Routes and Military Operations Area within which the Department of Defense conducts periodic operations involving Unmanned Aircraft Systems. These aircraft may be accompanied by military or other aircraft which provide the pilots of the Unmanned Aircraft Systems visual observation information about other aircraft operations near them. Status of these routes and areas may be obtained by contacting the FAA/DoD facility on designated frequencies along the IFR route, referencing the identifier, e.g., IR214 as depicted on this chart. The lateral limits of these specified routes are shown by the Special Use Airspace symbol. Altitudes for these route segments are also shown.



# FOREIGN AREAS

The data depicted in areas outside the U.S. is skeletonized on all VFR aeronautical charts. Only major airports, NAVAIDs, and airways are charted in foreign areas in screened black. Cultural features, hydrographic information and geographic relief are depicted in subdued and different shades of gray. A note regarding the expectation of the use of foreign charts and flight information publications is depicted along the boundary.



# **TERMINAL AREA CHART (TAC) COVERAGE**

TAC coverage is shown on appropriate Sectionals by a 1/4" masked line as indicated below. Within this area pilots should use TACs, which provide greater detail. A note indicating that the area is on the TAC appears near the masked boundary line.





# INSET AND SPECIAL CHART COVERAGE

Inset and Special Chart Coverage (.i.e., Grand Canyon Chart) is shown on appropriate Sectionals by a 1/8" masked line as indicated below. A note to this effect appears near the masked boundary line. (Additional examples shown in VFR Sectional and Terminal Charts > Navigational and Procedural Information > Chart Limits.)



# **CHART TABULATIONS**

**Airport Tower Communications** are provided in a columnized tabulation for all tower-controlled airports that appear on the respective chart. Airport names are listed alphabetically. If the airport is military, the type of airfield, e.g., AAF, AFB, NAS, is shown after the airfield name. In addition to the airport name, tower operating hours, primary Very High Frequency/Ultra High Frequency (VHF/UHF) local Control Tower (CT), Ground Control (GND CON), and Automatic Terminal Information Service (ATIS) frequencies, when available, will be given. Airport Surveillance Radar (ASR) and/or Precision Approach Radar (PAR) procedures are listed when available.

**Approach Control Communications** are provided in a columnized tabulation listing Class B, Class C, Terminal Radar Service Areas (TRSA) and Selected Approach Control Facilities when available. Primary VHF/UHF frequencies are provided for each facility. Sectorization occurs when more than one frequency exists and/or is approach direction dependent. Availability of service hours is also provided.

**Special Use Airspace (SUA):** Prohibited, Restricted and Warning Areas are presented in blue and listed numerically for U.S. and other countries. A tabulation of Alert Areas (listed numerically) and Military Operations Areas (MOA) (listed alphabetically) appear on the chart in magenta. All are supplemented with altitude, time of use and the controlling agency/ contact facility, and its frequency when available. Users need to be aware that a NOTAM addressing activation will NOT be issued to announce permanently listed times of use. The controlling agency will be shown when the contact facility and frequency data is unavailable.

Airports with control towers are indicated on the face of the chart by the letters CT followed by the primary VHF tower frequency(ies). Information for each tower is listed in the table below. Operational hours are local time. The primary VHF and UHF tower and ground control frequencies are listed.

Automatic Terminal Information Service (ATIS) frequencies shown on the face of the chart are arrival VHF/UHF frequencies. All ATIS frequencies are listed in the table below. ATIS operational hours may differ from tower operational hours. ASR and/or PAR indicate Radar Instrument Approach available.

"MON-FRI" indicates Monday through Friday.



Alert Areas do not extend into Class A, B, C and D airspace, or Class E airport surface areas.

MOA NAME	ALTITUDE*	TIME OF USE <sup>†</sup>	CONTROLLING AGENCY/ CONTACT FACILITY	FREQUENCIES
BRUSH CREEK	100 AGL TO BUT NOT INCL 5000	0800-2200 MON-SAT	INDIANAPOLIS CNTR	134.0 135.57
BUCKEYE	5000	0800-2200 MON-FRI 0800-1600 SAT-SUN	INDIANAPOUS CNTR	134.0 135.57
EVERS	1000 AGL	SR-SS BY NOTAM	WASHINGTON CNTR	

\*Altitudes indicate floor of MOA. All MOAs extend to but do not include FL 180 unless otherwise indicated in tabulation or on chart. †Other times by DoD NOTAM.

```
Sunrise to Sunset
```

# VFR SECTIONAL AND TERMINAL AREA CHARTS

# **GENERAL INFORMATION**

The symbols shown in this section illustrate those that appear in the Sectional Aeronautical Charts (Sectionals) and Terminal Area Charts (TACs). The same symbology is utilized in VFR Flyway Planning Charts, Helicopter Route Charts and Caribbean Aeronautical Charts (CACs), however the scale of the symbols may be different due to the particular chart scales. Where symbology is distinctive to a given chart, examples and explanations are given in the additional examples. These charts are updated every 56 days.

# AIRPORTS

Landplane: Civil Airports having control towers (CT) are shown in blue, all others are shown in magenta.	Non-Towered	Towered	Ultralight Flight Park (Selected)	Ē
All recognizable runways, including some that may be closed, are show for visual identification purposes. Fu available. Runway patterns will be depicted at airports with at least one hard surfaced runway 1500' or greater in length.	lel 🚯	<b>∲</b>	Landplane: Landmark Value	PUBLIC USE - (Soft surfaced runway, or hard surfaced runway less than 1500' in length.) Fuel not available. RESTRICTED OR PRIVATE -
Landplane: Civil-Military	Non-Towered	Towered	is not available.	<ul> <li>(Soft surfaced runway, or hard surfaced runway less than 1500' in length.) Non-public use having landmark value.</li> <li>OBJECTIONABLE</li> </ul>
Landplane: Military Refueling and repair facilities not indicated.	Non-Towered	Towered		<b>OBJECTIONABLE</b> is an airport that has an airspace determina- tion based upon a number of factors including conflicting traffic patterns with another airport, hazardous runway conditions, or natural or man-made obstacles in close proximity to the landing area.
Heliport (Selected)	Non-Towered	Towered		<b>UNVERIFIED</b> - A landing area available but warranting more than ordinary precaution due to:
Foreign  Foreign Airport Note	O			<ul> <li>(1) lack of current information on field conditions,</li> <li>and/or</li> <li>(2) available information indi-</li> </ul>
NOTE: Airports outside the U.S. are shown with the standard O Only the airport names and ICAC	symbol.		Appropriate note as required for hard surfaced runways only: "(CLOSED)"	cates peculiar operating limita- tions.

# **AIRPORTS (Continued)**

# Seaplane Facility No Fuel Facility With Fuel Facility With Runway and Waterway Image: Control of the second s

# **Airport Data Grouping**

Boxed airport name indicates airport for which a Special Traffic Rule has been established.

(Pvt): Non-public use having landmark value.

"OBJECTIONABLE": This airport may adversely affect airspace use.



Flight Service Station on field	FSS	Elevation in feet	285
Airports where fixed wing special VFR opera- tions are prohibited (shown above airport	NO SVFR	Lighting in operation Sunset to Sunrise	L
name) FAR 91		Lighting limitations exist; refer to Chart Supplement	*L
Indicates FAR 93 Special Air Traffic Rules and Airport Traffic Pattern		Length of longest runway in hundreds of feet; usable length may be less.	72
Location Identifier	(NAM)		
ICAO Location Identifier	(PNAM)	Aeronautical advisory station	122.95
Control Tower (CT) - primary frequency	ст - <b>118.3</b>	Runways with Right Traffic Patterns (public use)	RP 23,34
Star indicates operation part-time. See tower	*	See Chart Supplement	*RP
frequencies tabulation for hours of operation		VFR Advisory Service Shown when ATIS is not available and frequency is other than the	VFR Advsy <b>125.0</b>
Follows the Common Traffic Advisory Fre-	Θ	primary CT frequency.	
quency (CTAF)		Weather Camera (Alaska)	WX CAM
Automatic Terminal Information Services	ATIS 123.8	Airport of Entry	AOE
Automatic Flight Information Service	AFIS 135.2	When information is lacking, the respective	
Automated Surface Weather Observing Systems; shown when full-time ATIS is not available.	ASOS/AWOS 135.42	character is replaced by a dash. Lighting codes refer to runway edge lights and may not represent the longest runway or full length lighting.	

# **RADIO AIDS TO NAVIGATION**



25

# **RADIO AIDS TO NAVIGATION (Continued)**



#### **Class C Airspace**

Appropriate notes as required may be shown.

(Mode C see FAR 91.215/ AIM)





# FAA Chart Users' Guide - VFR Symbology - Sectional and Terminal Area Charts

# **Special Conservation Areas**

National Park, Wildlife Refuge, Primitive and Wilderness Areas, etc.



Special Flight Rules Area (SFRA) Relating to National Security

Example: Washington DC

Appropriate notes as required may be shown.

Note: Delimiting line not shown when it coincides with International Boundary, projection lines or other linear features.



METROPOLITAN AREA SFRA Washington DC Metropolitan Area Special

Flight Rules Area/Flight Restricted Zone (DC SFRA & DC FRZ) (See description in Atlantic Ocean). NOAA Regulated National Marine Sanctuary Designated Areas



Flight operations below 1000' AGL over the designated areas within the Gulf of Farallones National Marine Sanctuary violate NOAA regulations (see 15 CFR 922).



# Temporary Flight Restriction (TFR) Relating to National Security

Example: Washington DC

Appropriate notes as required may be shown.



CONTACT FLIGHT SERVICE FOR LATEST FLIGHT RESTRICTION STATUS AND NOTAMS ASSOCIATED WITH P-40 AND R-4009



# Special Flight Rules Area (SFRA)



Appropriate boxed note as required shown adjacent to area.

Inside the FAR Part 93 boundary area, the cross hatching is at a 45 degree angle. The hypsometric tint shall be masked within the area around the yellow city tint when applicable (should not be confused with white glacier tint).

/
///////////////////////////////////////

SPECIAL NOTICE Pilots are required to obtain an ATC clearance prior to entering this area.

# Flight Restricted Zone (FRZ) Relating to **National Security**



shown.

projection lines or other linear

features.



#### **VFR Transition Routes**

<sup>-</sup>AA Chart Users Guide - VFR Symbology - Sectional and Terminal Area Charts



# NAVIGATIONAL AND PROCEDURAL INFORMATION



# NAVIGATIONAL AND PROCEDURAL INFORMATION (Continued)

Airport Beacons				
Rotating or Flashing			<b>*</b>	ð
Isolated Locations			* <sup>2520</sup>	
VFR Checkpoints				_
Underline indicates proper name of VFR Checkpoint.	Pictorial		STA CAPI	
		R NORTHBF	) <u>LEWIS</u> 989	
Waypoints				
RNAV		$\diamond$	GRANT	
VFR Stand-Alone		¢	► VPXYZ	
VFR Collocated with Checkpo	int		NAME (VPXYZ)	
Obstruction				
Above 200' & below 1000' AG (above 299' AGL in urban area			<b>473</b> (394) bldg	
Under Construction (UC) or reposition/elevation unverified	ported and		5 <b>28</b> UC	
1000' and higher (AGL)			3 <b>368</b> 1529)	
Wind Turbine		Ť	<b>2179</b> (315)	
High-Intensity Obstructio	n Lights			
Less than 1000' (AGL)			*	
1000' and higher (AGL)			*	
Wind Turbine			Ť	
Group obstruction		*		X
Wind Turbines				
High-intensity lights may oper	ate part-time		<sup>−</sup> ľ <sup>1</sup>	

#### High-intensity lights may operate part-time or by proximity activation.

# **Marine Lights**

With Characteristics of Light	Oc R SEC
	Land Light
Red	R
White	*W
Green	G
Blue	BU
Orange	OR
Black	В
Yellow	Υ
Sector	SEC
Fixed	F
Single Occulting	Oc
Group Occulting	Oc (2)
Composite Group Occulting	Oc (2+1)
Isophase	lso
Flashing	FI
Group Flashing	FI (2)
Composite Group Flashing	Fl (2+1)
Quick	Q
Interrupted Quick/Interrupted Quick Fl	ashing 🛛
Morse Code	Mo (A)
Fixed and Flashing	FFI
Alternating	AI
Group	Gp
Long Flash	LFI
Group Quick Flashing	Q (3)
Very Quick Flashing	VQ
Group Very Quick Flashing	VQ (3)
Interrupted Very Quick Flashing	IVQ
Ultra Quick Flashing	UQ
Interuppted Ultra Quick Flashing	IUQ
* Marine Lights are white unless oth wise noted. Alternating lights are re otherwise noted.	
Group Obstruction	
Above 200' & below 1000' AGL	1062
(above 299' AGL in urban area)	<b>(</b> 227)
	4977
1000' and higher (AGL)	(1432)
At least two in group	2889
1000' and higher (AGL)	(1217)
5 ( )	
Wind Turbines	2735 (415)
Wind Turbine Farms	
When highest wind turbine is unverified, UC will be shown after MSL value.	2894 UC

# Maximum Elevation Figure (MEF)

(see VFR Terms tab for explanation)

135

# NAVIGATIONAL AND PROCEDURAL INFORMATION (Continued)

#### **Chart Limits Outline on Sectional of Inset Chart Outline on Sectional of Terminal Area Chart** INSET TAC If inset chart is on the same chart as outline: LOS ANGELES TERMINAL AREA Pilots are encouraged to use the Los Angeles VFF INDIANAPOLIS INSET Terminal Area Chart for flights at or below 10,000' See inset chart for additional detail If inset chart is on a different chart: **Outline of Special Chart on** INDIANAPOLIS INSET Sectional and Terminal Area See inset chart on the St. Louis Sectional for additional information **GRAND CANYON CHART** Chart CULTURE Railroads **Railroad Yards** Limiting Track To Scale railroad vard Single Track Location Only **Double Track** railroad yard **Railroad Stations** 3 tracks statlo More Than Two Tracks statio **Railroad Sidings and Short Spurs** electric Electric Non-operating, Abandoned or Under Construction under construction Roads **Road Markers Dual-Lane Divided Highway** Interstate Route No. (80) Category 1 (40) Primary U.S. Route No. Category 2 13 Air Marked Identification Label Secondary Category 2 **Road Names** LINCOLN HIGHWAY Trails **Roads Under Construction** under construction Category 3 \_\_\_\_\_ Provides symbolization for dismantled railroad when combined with label "dismantled railroad."

# **CULTURE (Continued)**

**Related Features to Railroads and Roads** 



Towns and Villages Category 3 - population less than 25,000

Frankfort

# **CULTURE (Continued)**




## HYDROGRAPHY

# **Inland Water Open Water Shorelines Open/Inland Water** Definite Lakes Fluctuating numerous small lakes Label as required. Unsurveyed Perennial Indefinite When too numerous to show 618 individual lakes, show 756 representative pattern and descriptive note. Number Man-made indicates elevation. **Non-Perennial** (dry, intermittent, etc.) Illustration includes small perennial lake. Reservoirs Natural Shorelines Man-made Shorelines reservoir Label when necessary for clarity Too small to show to scale **Under Construction** under construction







of the of

## HYDROGRAPHY (Continued)



## HYDROGRAPHY (Continued)



## **HYDROGRAPHY** (Continued)

## **Permanent Snow and Ice Areas**



## **RELIEF (Continued)**

## Sand or Gravel Areas



RELIEF DATA INCOMPLETE

FAA Chart Users' Guide - VFR Symbology - Sectional and Terminal Area Charts

# **VFR FLYWAY PLANNING CHARTS**

## **GENERAL INFORMATION**

**VFR Flyway Planning Charts** are printed on the reverse sides of the Baltimore-Washington, Charlotte, Chicago, Cincinnati, Dallas-Ft. Worth, Denver, Detroit, Houston, Las Vegas, Los Angeles, Miami, Orlando, New Orleans, Phoenix, St. Louis, Salt Lake City, San Diego, San Francisco, Seattle, and Tampa Terminal Area Charts (TACs). The scale is 1:250,000, with area of coverage the same as the associated TACs. Flyway Planning Charts depict flight paths and altitudes recommended for use to by-pass areas heavily traversed by large turbine-powered aircraft. Ground references on these charts provide a guide for visual orientation. VFR Flyway Planning charts are designed for use in conjunction with TACs and are not to be used for navigation. These charts are updated every 56 days.



## AIRSPACE INFORMATION

### **Class B Airspace**



Flight Restricted Zone (FRZ) Relating To National Security

Example: Washington DC



NOTE: Limited chart information provided outside of U.S. airspace. Refer to DoD (NGA) or foreign charts and flight information publications outside U.S. airspace.

# Temporary Flight Restriction (TFR) Relating To National Security

## Example: Washington DC

Appropriate notes as required may be shown.

## Special Use Airspace

Only the airspace effective below 18,000 feet MSL is shown.

The type of area shall be spelled out in large areas if space permits.

200000				
P-56	or R-64	O1 or	W-518	
PRC	HIBITED, or WARNII	RESTR	ICTED	
FALCO	ON 1		631	
МО	ON 1	r A		

#### Special Air Traffic Rules/Airport Traffic Areas (FAR Part Mode C (FAR 91.215) 93) MODE C & ADS-B OUT Appropriate notes as required may 30 NM Appropriate boxed note as rebe shown. quired shown adjacent to area. Inside the FAR Part 93 bound-Sporting Event Temporary Flight Restriction (TFR) ary area, the cross hatching is Sites at a 45 degree angle. STADIUM National Defense Airspace Temporary Flight Restric-**Terminal Radar Service Area (TRSA)** tion (TFR) Areas PALM SPRINGS TRSA TRSA SURFACE AREA **Dallas National** 100 - Celling of TRSA In hundreds of feet MSL Defense Airspace TFR Check NOTAMs 90 - Floor of TRSA In hundreds of feet MSL **IFR Routes Miscellaneous Activity Areas** 15 000 - 7000 Arrival Aerobatic Practice Area **Glider Operations** Departure 8000 - 12000 Hang Glider Activity IFR DEPARTURES IFR ARRIVALS Arrival/Departure Ultralight Activity 8000 - 5000 5000 - 8000 **VFR Transition Routes** Unmanned Aircraft Activity VFR TRANSITION ROUTE ATC CLEARANCE REQUIRED SEE SHOWBOAT GRAPHIC Parachute Jumping Area Appropriate notes as required 122.9 may be shown. ON SIDE PANEL with Frequency Space Launch Activity Area Uni-directional **Bi-directional** Example: Los Angeles WOODLEY (CPM) INTERCHANGE (VPLFX) VNY 140° 405 LONG BEACH/ Bi-directional with NAVAID Ident YS DAUGHERTY (LGB) and Radial HF 26 **Special Conservation Areas** 13,000 SIGNAL HILL NOAA Regulated National Marine SO 3000 - 6000 Π Sanctuary Designated Areas QUEEN MARY Flight operations below 1000' AGL (VPLQM) over the designated areas within the Gulf of Farallones National Marine Sanctuary violate NOAA regulations VORTA 100

(see 15 CFR 922).

0

SLI/115.



## NAVIGATIONAL AND PROCEDURAL INFORMATION

## **VFR Checkpoints**



## CULTURE



Position Accurate Mountain Peaks

# **HELICOPTER ROUTE CHARTS**

## **GENERAL INFORMATION**

**Helicopter Route Charts** are three-color charts that depict current aeronautical information useful to helicopter pilots navigating in areas with high concentrations of helicopter activity. Information depicted includes helicopter routes, four classes of heliports with associated frequency and lighting capabilities, NAVAIDS, and obstructions. In addition, pictorial symbols, roads, and easily-identified geographical features are portrayed. The scale is 1:125,000. These charts are updated every 56 days.

## AIRPORTS

Landplane		Seaplane	
All recognizable runways, including some that may be closed, are shown		Heliport	
for visual identification.		Heliports public and private	(H)
Public	0	Medical Center	$\oplus$
Private	R	Helipads located at major airports	Θ
Unverified	$\bigcirc$	(when requested)	
Abandoned	$\boxtimes$	Ultralight Flight Park	F
Foreign	$\bigcirc$	Foreign Airport Note	
		NOTE: Airports outside the U.S. Flight Inform are shown with the standard O symbol. Only the airport names and ICAO identifiers	-
Airport Data Grouping		FSS NO SVFR	
Boxed airport name indicates airport for which a Rule has been established.	Special Traffic	No SVFR     [NAME] (NAM) (PNAM     CT - 119,1 + 0 (119,8     ATIS 115,4     ASOS/NVOS 135,4     ASOS	HELI)
(Pvt): Non-public use having landmark value. "OBJECTIONABLE": This airport may adversely use.	affect airspace	Automated Terminal Information Service	ATIS 115.4
Flight Service Station on field	FSS	Automated Surface Weather Observing Systems (shown when full-time ATIS is not	ASOS/AWOS 135.42
Airspace where fixed wing special visual flight rules operations are prohibited (shown above airport name) FAR 91	NO SVFR	available). Some ASOS/AWOS facilities may not be located at airports.	
		Elevation in feet	285
Indicates FAR 93 Special Air Traffic Rules and Airport Traffic	NAME	Lighting in operation Sunset to Sunshine	L
		Lighting limitations exists, refer to Chart Supplement	ч
Location Idendtifier	(NAM)		
ICAO Location Identifier	(PNAM)	UNICOM - Aeronautical advisory station	122.95
Control Tower (CT) - primary frequency	ст - 119.1	Follows the Common Traffic Advisory Frequency (CTAF)	Ю
Star indicates operation part-time. See tower	*	Unverified Heliport	(Unverified)
frequencies tabulation for hours of operation		Airport of Entry	AOE

When lighting is lacking, the respective character is replaced by a dash.

Lighting codes refer to runway edge lights and may not represent the longest runway or full length lighting. Dashes are not shown on heliports or helipads unless additional information follows the elevation (e.g. UNICOM, CTAF).

## **RADIO AIDS TO NAVIGATION**

## **NAVAIDs**

## VHF Omni-Directional Radio (VOR) Range

VOR-DME

AMEDEE

**Open Circle** 

OAKDALE

116.8 OAK

Underline indicates no voice on this frequency

PONTIAC 111.0 Ch 47 PSI

Channel

Crosshatch indicates Shutdown status

122.1R

SALEM

...-

Operates less than contiuous or On-Request

NDB Frequency

 $\odot$ 

Frequency

 $(\bullet)$ 

•



VOR



FAA Chart Users' Guide - VFR Chart Symbology - Helicopter Charts



VORTAC

DME

When an NDB NAVAID shares the same name and Morse Code as the VOR NAVAID the frequency can be collocated inside the same box to conserve space.

**VOR-DME** 

# Heavy line box indicates Flight

Service Station (FSS). Frequencies 121.5, 122.2 and 243.0 are available at many Alaskan FSSs and are not shown above boxes. All other frequencies are shown.

Flight Service Station (FSS)

Certain FSSs provide Airport Advisory Service, refer to Chart Supplement.

R - Receive Only



FSS oper 0600-2200 Rancho Murieta FSS other times

PROVO

Ch 21 PVU



available as determined by altitude and terrain. Consult Chart Supplement for complete information.

Thin line box without frequencies and controlling FSS name indicates no FSS frequency available.





## **AIRSPACE INFORMATION**

#### **Class B Airspace Class C Airspace BURBANK CLASS C** LAS VEGAS CLASS B Appropriate notes as required Appropriate notes as required may be shown. (Mode C see FAR NAVAID identifier and may be shown. (Mode C see distance from facility FAR 91.215/AIM) 91.215/AIM) LAS ROWN See NOTAMs/Supplement for Class C eff hrs All mileages are nautical (NM) CLASS C SURFACE AREA NAVAID identifier and (Floors extending "upward from radial from facility above" a certain altitude are Ceiling of Class C in preceded by a +. Operations at **CLASS B** 70 hundreds of feet MSL and below these altitudes are SURFACE AREA 30 Floor of Class C in outside of Class B Airspace.) hundreds of feet MSL Ceiling of Class B in All radials are magnetic. **Ceiling is to but not** 70 hundreds of feet MSL including floor of Class B 1 SFC Floor of Class B in SFC hundreds of feet MSL Surface CTC BURBANK APP WITHIN CTC LAS VEGAS APP ON 121.1 OR 257.8 20 NM ON 124.6 395.9 Class E Surface (SFC) Airspace **Class D Airspace** See NOTAMs/Supplement for Class E (sfc) eff hrs See NOTAMs/Supplement for Class D eff hrs (A minus in front of the figure is used to indicate "from surface to but not including...") 31 Altitudes in hundreds of feet MSL. See NOTAMs/Supplemer Class D/E (sfc) eff hrs -20

## **Special Airspace Areas**

# Special Flight Rules Area (SFRA) Relating to National Security

Example: Washington DC

Appropriate notes as required may be shown.

Note: Delimiting line not shown when it coincides with International Boundary, projection lines or other linear features.





Metropo	litan Are	a Soecia	Hight Rules
tricted Zo	ine restri	ctions ar	e in effect.
a apply to i	all aircraft	operation	s from the
securing s	aget Leve	H 180 M 18	e Washington
Pictuare	uld conta	ct Filon S	ervice for NOT



## **Special Airspace Areas (Continued)**

Flight Restricted Zone (FRZ) Relating to National Security

## Example: Washington DC



# FAA Chart Users' Guide - VFR Chart Symbology - Helicopter Charts

features.

required

#### 301 Special Air Traffic Rules / Airport Traffic Areas Air Defense Identification Zone (ADIZ) (FAR Part 93) CONTIGUOUS Note: Delimiting line not U.S. ADIZ shown when it coincides Appropriate boxed notes as with International Boundary, required shown adjacent to projection lines or other linear area. Inside the FAR Part 93 boundary area, the cross hatching is at a 45 degree **Special Security Notice Permanent Continuous** SPECIAL NOTICE angle. Pilots are required to obtain an ATC clearance **Flight Restriction Areas** prior to entering this area. Sporting Event Temporary Flight Restriction (TFR) **DISNEYLAND THEME PARK** See Panel for requirements Sites STADIUM Mode C (FAR 91.215) MODE C & ADS-B OUT National Defense Airspace Temporary Flight Restric-Appropriate notes as required 30 NM tion (TFR) Areas may be shown. **Terminal Radar Service Area (TRSA)** PALM SPRINGS TRSA Appropriate notes as may be shown. TRSA SURFACE AREA Dallas National **Defense Airspace TFR** Check NOTAMs SEE TWR FREQ TAB

80 - Ceiling of TRSA in hundreds of feet MSL 40 - Floor of TRSA in hundreds of feet MSL

Miscellaneous Activity Areas		Police Zones	
Aerobatic Practice Area			<u>ZONE 8</u> 1000
Glider Operations			
Hang Glider Activity		Special Use Airspace	
Ultralight Activity		Only the airspace effective	
Unmanned Aircraft Activity	<u>UA</u>		6 or R-6401 or W-518
Parachute Jumping Area with Frequency	<b>P</b> 122.9	I The type of area shall be	ROHIBITED, RESTRICTED or WARNING AREA
Space Launch Activity Area	*	space permits.	
		FAL	CON 1 or A-631
Military Training Routes (MTR)			
-		MILITAF	RY OPERATIONS AREA (MOA) or ALERT AREA
Helicopter Routes			
Primary Route with Route Name and Tower Frequency	MARRIOT 118.3	One-way Route	*
Secondary Route		Altitude Changeover Point	
Transition Symbol	** ** ** ** ** **		
Reporting Points		Recommended Altitudes	
		Maximum Altitude	500
Non-compulsory	$\bigtriangleup$	Minimum Altitude	500
Compulsory	<b>A</b>		
Reporting Point Name	BAHAI	Recommended Altitude	500

## Foreign Airspace Note

NOTE: Limited chart information provided outside of U.S. airspace. Refer to DoD (NGA) or foreign charts and flight information publications outside U.S. airspace.

## **Special Conservation Areas**

National Park, Wildlife Refuge, Primitive and Wilderness Areas, etc.



NOAA Regulated National Marine Sanctuary Designated Areas



Flight operations below 1000' AGL over the designated areas within the Gulf of Farallones National Marine Sanctuary violate NOAA regulations (see 15 CFR 922).

## NAVIGATIONAL AND PROCEDURAL INFORMATION



## CULTURE

## Railroads

Single Track
Double Track
Bridges
Populated Places
Built-up Areas



FAA Chart Users' Guide - VFR Chart Symbology - Helicopter Charts

# CARIBBEAN VFR AERONAUTICAL CHARTS (CAC)

The Caribbean Charts are published as two VFR Charts: Caribbean 1 (CAC-1) covers Southern Florida, Cuba, Haiti and the Bahamas; Caribbean 2 (CAC-2) covers Puerto Rico, Haiti, Dominican Republic, the Lesser Antilles and Leeward Islands. Charts are updated every 56-day chart cycle.

Caribbean Charts are designed for VFR flights and provide aeronautical and topographic information of the Caribbean. The aeronautical information includes airports, radio aids to navigation, Class airspace and special use airspace in U.S. and major airports, and radio aids to navigation in foreign areas. The topographic information includes city tint, populated places, principal roads, drainage patterns and shaded relief.

The chart symbols used on the Caribbean Charts are similar to those used in the Sectional and Terminal Area Charts, the major difference being in scale. The Caribbean VFR Chart scale is 1:1,000,000 versus the Sectional Chart Scale of 1:500,000 and Terminal Area Chart Scale of 1:250,000. Chart symbology will appear smaller on the Caribbean VFR Charts.

Example from Caribbean 2 VFR Aeronautical Chart





FAA Chart Users' Guide - Caribbean VFR Aeronautical Charts (CAC)

# AIRSPACE



U.S. Airspace depiction as shown on Visual Aeronautical Charts



Excerpt from Detroit Sectional Chart

# **EXPLANATION OF IFR ENROUTE TERMS**

FAA charts are prepared in accordance with specifications of the Interagency Air Committee (IAC), and are approved by representatives of the Federal Aviation Administration and the Department of Defense (DoD). Some information on these charts may only apply to military pilots.

The explanations of symbols used on Instrument Flight Rule (IFR) Enroute Charts and examples in this section are based primarily on the IFR Enroute Low Altitude Charts. Other IFR products use similar symbols in various colors. The chart legends portray aeronautical symbols with a brief description of what each symbol depicts. This section provides more details of the symbols and how they are used on IFR Enroute charts.

## AIRPORTS

Operational airports are shown on IFR Enroute Charts.

Low Charts:

- All IAP Airports are shown on the Low Altitude Charts (US and Alaska).
- Non-IAP Airports are shown on the U.S. Low Altitude Charts (Contiguous US) have a minimum hard surface runway of 3,000'.
- Non-IAP airports are shown on the U.S. Low Altitude Alaska Charts are show if the runway is 3000' or longer, hard or soft surface.
- Public heliports with an Instrument Approach Procedure (IAP) or requested by the FAA or DoD are depicted on the IFR Enroute Low Altitude Charts.
- Seaplane bases requested by the FAA or DoD are depicted on the IFR Enroute Low Altitude Charts.

On IFR Enroute Low Altitude Charts, airport tabulation is provided that identifies airport names, IDs and the panels they are located on.

High Charts:

- Airports shown on the U.S. High Enroute Charts (Contiguous US) have a minimum hard surface runway of 5000'.
- Airports shown on the U.S. High Enroute Alaska Charts have a minimum hard surface runway of 4000'.

Charted airports are classified according to the following criteria:



**Blue** - Airports with an Instrument Approach Procedure and/or RADAR MINIMA published in the high altitude DoD Flight Information Publications (FLIPs)

**Green** - Airports that have an approved Instrument Approach Procedure and/or RADAR MINIMA published in either the U.S. Terminal Procedures Publications (TPPs) or the DoD FLIPs

Brown - Airports without a published Instrument Approach Procedure or RADAR MINIMA

Black - Foreign airports

Airports are plotted at their true geographic position.

Airports are identified by the airport name. In the case of military airports, Air Force Base (AFB), Naval Air Station (NAS), Naval Air Facility (NAF), Marine Corps Air Station (MCAS), Army Air Field (AAF), etc., the abbreviated letters appear as part of the airport name.

Airports marked "Pvt" immediately following the airport name are not for public use, but otherwise meet the criteria for charting as specified above.

Runway length is the length of the longest active runway (including displaced thresholds but excluding overruns) and is shown to the nearest 100 feet using 70 feet as the division point; e.g., a runway of 8,070' is labeled 81. The following runway compositions (materials) constitute a hard-surfaced runway: asphalt, bitumen, chip seal, concrete, and tar macadam. Runways that are not hard-surfaced have a small letter "s" following the runway length, indicating a soft surface.

AIRPORT DATA DEPICTION	
Minimum Operational Network Airport Designator       Mon CITY       Part-time or established by NOTAM. See Chart Supplement for times of operation.         Low Altitude       Airport Ident ICAO Location Indicator shown outside contiguous U.S. Airport Elevation       Airport Name (APT) (ICAO) (ICAO) (ICAO)       Part-time or established by NOTAM. See Chart Supplement for times of operation.         Low Altitude       Airport Ident ICAO Location Indicator shown outside contiguous U.S. Airport Elevation       Airport Name (APT) (ICAO) (ICAO) (ICAO)       Longest runway length to nearest 100 feet with 70 feet as the dividing point (add 00) s indicates soft surface         ATIS or AFIS (Alaska Only)       Part-time       Frequency Lighting Capability:       ASOS/AWOS	
<ol> <li>Airport elevation given in feet above or below mean sea level</li> <li>Pvt - Private use, not available to general public</li> <li>A solid line box enclosed the airport name indicates FAR 93 Special Requirements - see Directory/Supplement</li> <li>"NO SVFR" above the airport name indicates FAR 91 fixed- wing special VFR flight is prohibited.</li> <li>C or D following the airport identifier indicates Class C or Class D Airspace</li> <li>High Altitude - U.S.</li> </ol>	<ul> <li>6. Associated city names for public airports are shown above or preceding the airport name. If airport name and city name are the same, only the airport name is shown. The airport identifier in parentheses follows the airport name. City names for military and private airports are not shown.</li> <li>7. Airport Ident ICAO Location Indicator shown outside contiguous U.S.</li> <li>8. AFIS Alaska only</li> <li>Minimum Operational Network Airport Designator Shown outside City City City City City City City City</li></ul>
	★ Part-time or on request
L Lighting Available	<ul> <li>Part-time or on request</li> <li>No lighting available</li> <li>At private facilities- indicates no lighting information is available</li> </ul>

A symbol between the airport elevation and runway length means that runway lights are in operation sunset to sunrise.

A () symbol indicates there is Pilot Controlled Lighting. A 📩 symbol means the lighting is part-time or on request, the pilot should consult the Chart Supplement for light operating procedures. The Aeronautical Information Manual (AIM) thoroughly explains the types and uses of airport lighting aids.

## VOR Minimum Operational Network (MON) Airports Designator

MON Airports with the Airport designator at the top of the Airport Data Block. The MON designation is to alert pilots to those airports that have retained ILS and VOR instrument approach procedures for safe recovery in the event of a GPS outage. Refer to the Aeronautical Information Manual (AIM) for expanded MON Airport guidance.

## **RADIO AIDS TO NAVIGATION**

All IFR radio NAVAIDs that have been flight checked and are operational are shown on all IFR Enroute Charts. Very High Frequency/Ultrahigh Frequency (VHF/UHF) NAVAIDs, Very high frequency Omnidirectional Radio range (VORs), Tactical Air Navigation (TACANs) are shown in black, and Low Frequency/Medium Frequency (LF/MF) NAVAIDs, (Compass Locators and Aeronautical or Marine NDBs) are shown in brown.

On IFR Enroute Charts, information about NAVAIDs is boxed as illustrated below. To avoid duplication of data, when two or more NAVAIDs in a general area have the same name, the name is usually printed only once inside an identification box with the frequencies, TACAN channel numbers, identification letters, or Morse Code Identifications of the different NAVAIDs are shown in appropriate colors.

NAVAIDs in a shutdown status have the frequency and channel number crosshatched. Use of the NAVAID status "shutdown" is only used when a facility has been decommissioned but cannot be published as such because of pending airspace actions.

NAVIGATION AND COMMUNICATION BOXES - COMMON ELEMENTS		
LOW ENROUTE CHARTS	HIGH ENROUTE CHARTS	
RCO Frequencies       000.0         NAVAID Name, SSV(s)       NAME (VL) (T)         FREQ, Ident, CH, Morse Code       000.0 IDT 000 \u2006.00'         Latitude, Longitude       N00*00.00' W000*00.00'         Controlling FSS Name	RCO Frequencies     000.0       NAVAID Name     NAME       Frequency, Ident, SSV(s), Channel     IDT (H) (DL) 000       Latitude, Longitude     w00000.00'       Controlling FSS Name     NAME_	
COMMON ELEMENTS (HIGH AND LOW CHARTS)		
RCO FREQUENCY Single Frequency	122.6	
Multiple FrequenciesFrequencies transmit and receive except those followed by R andT:R - Receive OnlyT - Transmit Only	255.4 243.0 123.6 122.65 122.2 122.1R 121.5	
NAVAID BOX	VHF/UHF LF/MF	
Thin line NAVAID boxes without frequency(s) and FSS radio name indicates no FSS frequencies available.		
Shadow NAVAID box indicates NAVAID and Flight Service Station (FSS) have same name.		

SSV Class	Altitudes	Distance (NM)
T) Terminal	1000' to 12,000'	25
_) Low Altitude	1000' to 18,000'	40
H) High Altitude	1000' to 14,500' 14,500' to 18,000' 18,000' to 45,000' 45,000' to 60,000'	40 100 130 100
L) VOR Low	1000' to 5,000' 5,000' to 18,000'	40 70
VH) VOR High	1000' to 5,000' 5,000' to 14,500' 14,500' to 18,000' 18,000' to 45,000' 45,000' to 60,000'	40 70 100 130 100
DL) DME Low & (DH) DME High*	1000' to 12,900'	40 increasing to 130
DL) DME Low	12,900' to 18,000'	130
DH) DME High	12,900' to 45,000' 45,000' to 60,000'	130 100

\* Between 1000' to 12,900', DME service volume follows a parabolic curve used by flight managment computers.

**Notes:** For NAVAIDs with two SSVs, the SSV for each component is shown in paired parentheses with the VOR SSV shown first followed by the DME or TACAN SSV. Additionally, High Altitude facilities provide Low Altitude and Terminal service volume and Low Altitude facilities provide Terminal service volume. Altitudes are with respect to the station's site elevation. Coverage is not available in a cone of airspace directly above the facility. In some cases local conditions (terrain, buildings, trees, etc.) may require that the service volume be restricted. The public shall be informed of any such restriction by a remark in the NAVAID entry or by a NOTAM.

DISTANCE MEASURING EQUIPMENT	
Facilities that operate in the "Y" mode for DME reception	(Y)
VOICE COMMUNICATIONS VIA NAVAID	
Voice Transmitted	112.6
No Voice Transmitted	111.0
NAVAID SHUTDOWN STATUS	VHF/UHF LF/MF
PART TIME OR ON-REQUEST	VHF/UHF LF/MF ★ ★
AUTOMATED WEATHER BROADCAST SERVICES ASOS/AWOS - Automated Surface Observing Station/Automated Weather Observing Station	VHF/UHF LF/MF
	Automated weather, when available, is broadcast on the associated NAVAID frequency.
LATITUDE AND LONGITUDE Latitude and Longitude coordinates are provided for those NAVAIDs that make up part of a route/airway or a holding pattern. All TACAN facilities will include geographic coordinates.	LOW ENROUTE HIGH ENROUTE N00°00.00' W000°00.00' N000°00.00' W000°00.00' W000°00.00' W000°00.00'

## AIRSPACE INFORMATION

## CONTROLLED AIRSPACE

Controlled airspace consists of those areas where some or all aircraft are subjected to air traffic control within the following airspace classifications of A, B, C, D, & E.

Air Route Traffic Control Centers (ARTCC) are established to provide Air Traffic Control to aircraft operating on IFR flight plans within controlled airspace, particularly during the enroute phase of flight. Boundaries of the ARTCCs are shown in their entirety using the symbol below.

MEN YORK Air Route Traffic Control Center (ARTCC)

When Controller Pilot Data Link Communication (CPDLC) exists for an ARTCC, the text CPDLC (LOGON KUSA) will be shown parallel to the boundary above or below the ARTCC identification as shown below.



Air Route Traffic Control Center (ARTCC) with Controller Pilot Data Link Communication (CPDLC)

The responsible ARTCC Center names are shown adjacent and parallel to the boundary line. ARTCC sector frequencies are shown in boxes outlined by the same symbol.



ARTCC Remoted Sites with discrete VHF and UHF frequencies

**Class A** Airspace is depicted as open area (white) on the IFR Enroute High Altitude Charts. It consists of airspace from 18,000 Mean Sea Level (MSL) to FL600.

**Class B** Airspace is depicted as screened blue area with a solid line encompassing the area.

**Class C** Airspace is depicted as screened blue area with a dashed line encompassing the area with a letter "C" enclosed in a box following the airport name.

Class B and Class C Airspace consist of controlled airspace extending upward from the surface or a designated floor to specified altitudes, within which all aircraft and pilots are subject to the operating rules and requirements specified in the Federal Aviation Regulations (UHF) 71. Class B and C Airspace are shown in abbreviated forms on IFR Enroute Low Altitude Charts. A general note adjacent to Class B airspace refers the user to the appropriate VFR Terminal Area Chart.

**Class D** Airspace (airports with an operating control tower) are depicted as open area (white) with a letter "D" enclosed in a box following the airport name.

**Class E** Airspace is depicted as open area (white) on the IFR Enroute Low Altitude Charts. It consists of airspace below FL180.

#### UNCONTROLLED AIRSPACE

**Class G** Airspace within the United States extends to 14,500' MSL. This uncontrolled airspace is shown as screened brown.

#### SPECIAL USE AIRSPACE

Special Use Airspace (SUA) confines certain flight activities, restricts entry, or cautions other aircraft operating within specific boundaries. SUA areas are shown in their entirety, even when they overlap, adjoin, or when an area is designated within another area. SUA with altitudes from the surface and above are shown on the IFR Enroute Low Altitude Charts. Similarly, SUA that extends above 18,000' MSL are shown on IFR Enroute High Altitude Charts. IFR Enroute Charts tabulations identify the type of SUA, ID, effective altitudes, times of use, controlling agency and the panel it is located on.

Users need to be aware that a NOTAM addressing activation will NOT be issued to announce permanently listed times of use.



WALL 1	Ľ
WALL 2 MOA	

Line delimits internal		
separation of same		
Special Use Area		

High and Low	Low Altitude Only	
P - Prohibited Area	MOA - Military Operations Area	
R - Restricted Area	A - Alert Area *	
W - Warning Area		
* Alert Areas do not extend into Class A, B, C and D airspace, or Class E airport surface areas.		
See Airspace Tabulation on chart for complete information.		

## OTHER AIRSPACE

FAR 91 Special Air Traffic Rules are shown with the type NO SVFR above the airport name.



**FAR 93 Special Airspace Traffic Rules** are shown with a solid line box around the airport name, indicating FAR 93 Special Requirements see Chart Supplement.



**Mode C Required Airspace** (from the surface to 10,000' MSL) within 30 NM radius of the primary airport(s) for which a Class B airspace is designated, is depicted on IFR Enroute Low Altitude Charts as a blue circle labeled MODE C & ADS-B OUT 30 NM.



Mode C & ADS-B Out is also required for operations within and above all Class C airspace up to 10,000' MSL, but not depicted. See FAR 91.215 and the AIM.

## **INSTRUMENT AIRWAYS**

The FAA has established two fixed route systems for air navigation. The VOR and LF/MF system-designated from 1,200' Above Ground Level (AGL) to but not including FL 180 is shown on IFR Enroute Low Altitude Charts, and the Jet Route system designated from FL 180 to FL 450 inclusive is shown on IFR Enroute High Altitude Charts.

## VOR LF/MF AIRWAY SYSTEM (IFR LOW ALTITUDE ENROUTE CHARTS)

In this system VOR airways - airways based on VOR or VORTAC NAVAIDs - are depicted in black and identified by a "V" (Victor) followed by the route number (e.g., "V12").

LF/MF airways - airways based on LF/MF NAVAIDs - are sometimes called "colored airways" because they are identified by color name and number (e.g., "Amber One", charted as "A1"). In Alaska, Green and Red airways are plotted east and

west, and Amber and Blue airways are plotted north and south. Regardless of their color identifier, LF/MF airways are shown in brown.

## **AIRWAY/ROUTE DATA**

On both series of IFR Enroute Charts, airway/route data such as the airway identifications, magnetic courses bearings or radials, mileages, and altitudes (e.g., Minimum Enroute Altitudes (MEAs), Minimum Reception Altitudes (MRAs), Maximum Authorized Altitudes (MAAs), Minimum Obstacle Clearance Altitudes (MOCAs), Minimum Turning Altitudes (MTAs) and Minimum Crossing Altitudes (MCAs)) are shown aligned with the airway.

As a rule the airway/route data is charted and in the same color as the airway, with one exception. Charted in blue, Global Navigation Satellite System (GNSS) MEAs, identified with a "G" suffix, have been added to "V" and "colored airways" for aircraft flying those airways using Global Positioning System (GPS) navigation.

Airways/Routes predicated on VOR or VORTAC NAVAIDs are defined by the outbound radial from the NAVAID. Airways/ Routes predicated on LF/MF NAVAIDs are defined by the inbound bearing.

- **Minimum Enroute Altitude (MEA)** The MEA is the lowest published altitude between radio fixes that assures acceptable navigational signal coverage and meets obstacle clearance requirements between those fixes. The MEA prescribed for a Federal airway or segment, RNAV low or high route, or other direct route applies to the entire width of the airway, segment, or route between the radio fixes defining the airway, segment, or route. MEAs for routes wholly contained within controlled airspace normally provide a buffer above the floor of controlled airspace consisting of at least 300 feet within transition areas and 500 feet within control areas. MEAs are established based upon obstacle clearance over terrain and man-made objects, adequacy of navigation facility performance, and communications requirements.
- **Minimum Reception Altitude (MRA)** MRAs are determined by FAA flight inspection traversing an entire route of flight to establish the minimum altitude the navigation signal can be received for the route and for off-course NAVAID facilities that determine a fix. When the MRA at the fix is higher than the MEA, an MRA is established for the fix and is the lowest altitude at which an intersection can be determined.
- **Maximum Authorized Altitude (MAA)** An MAA is a published altitude representing the maximum usable altitude or flight level for an airspace structure or route segment. It is the highest altitude on a Federal airway, jet route, RNAV low or high route, or other direct route for which an MEA is designated at which adequate reception of navigation signals is assured.
- **Minimum Obstruction Clearance Altitude (MOCA)** The MOCA is the lowest published altitude in effect between radio fixes on VOR airways, off-airway routes, or route segments that meets obstacle clearance requirements for the entire route segment and assures acceptable navigational signal coverage only within 25 statute (22 nautical) miles of a VOR. A MOCA is only shown on the Enroute Low Charts and only published when it is lower than the MEA. When shown, it is preceded by an asterisk.
- Minimum Turning Altitude (MTA) Minimum turning altitude (MTA) is a charted altitude providing vertical and lateral obstruction clearance based on turn criteria over certain fixes, NAVAIDs, waypoints, and on charted route segments. When a VHF airway or route terminates at a NAVAID or fix, the primary area extends beyond that termination point. When a change of course on VHF airways and routes is necessary, the enroute obstacle clearance turning area extends the primary and secondary obstacle clearance areas to accommodate the turn radius of the aircraft. Since turns at or after fix passage may exceed airway and route boundaries, pilots are expected to adhere to airway and route protected airspace by leading turns early before a fix. The turn area provides obstacle clearance for both turn anticipation (turning prior to the fix) and flyover protection (turning after crossing the fix). Turning fixes requiring a higher MTA are charted with a flag along with accompanying text describing the MTA restriction.

• **Minimum Crossing Altitude (MCA)** - An MCA is the lowest altitude at certain fixes at which the aircraft must cross when proceeding in the direction of a higher minimum enroute IFR altitude. MCAs are established in all cases where obstacles intervene to prevent pilots from maintaining obstacle clearance during a normal climb to a higher MEA after passing a point beyond which the higher MEA applies. The same protected enroute area vertical obstacle clearance requirements for the primary and secondary areas are considered in the determination of the MCA.



Victor Route (with RNAV/GPS MEA shown in blue)

## AREA NAVIGATION (RNAV) "T" ROUTE SYSTEM

The FAA has created new low altitude area navigation (RNAV) "T" routes for the enroute and terminal environments. The RNAV routes will provide more direct routing for IFR aircraft and enhance the safety and efficiency of the National Air-space System. To utilize these routes aircraft are required to be equipped with IFR approved GNSS. In Alaska, TSO-145a and 146a equipment is required.

Low altitude RNAV only routes are identified by the prefix "T", and the prefix "TK" for RNAV helicopter routes followed by a three digit number (T-200 to T-500). Routes are depicted in blue on the IFR Enroute Low Altitude Charts. RNAV route data (route line, identification boxes, mileages, waypoints, waypoint names, magnetic reference courses and MEAs) will also be printed in blue. Magnetic reference courses will be shown originating from a waypoint, fix/reporting point or NAVAID. GNSS MEA for each segment is established to ensure obstacle clearance and communications reception. GNSS MEAs are identified with a "G" suffix.



Joint Victor/RNAV routes are charted as outlined above except as noted. The joint Victor route and the RNAV route identification boxes are shown adjacent to each other. Magnetic reference courses are not shown. MEAs are charted above the appropriate identification box or stacked in pairs, GNSS and Victor. On joint routes, RNAV specific information will be printed in blue.



## UNUSABLE AIRWAY/ROUTE SEGMENTS

Airway/Route segments designated by the FAA as unusable will be depicted as shown below.



FAA Chart Users' Guide - IFR Enroute Terms

Pilots should not file a flight plan for or accept a clearance that includes navigation on any route or route segment depicted as unusable. Pilots using RNAV may request ATC clearance to fly point-to-point between valid waypoints or fixes, even those on routes depicted as unusable (refer to AC 90-108 for RNAV eligibility).

## **Coincident Airways/Routes with Unusable Segment**

When two airways/routes are coincident, but only one airway/route is designated as unusable, the following note indicating which airway the unusable symbology applies to will be placed in close proximity to the airway/route identifiers.



## OFF ROUTE OBSTRUCTION CLEARANCE ALTITUDE (OROCA)

The Off Route Obstruction Clearance Altitude (OROCA) is depicted on IFR Enroute Low Altitude and Pacific charts and is represented in thousands and hundreds of feet above MSL. OROCAs are shown in every 30 x 30 minute quadrant on Area Charts, every one degree by one degree quadrant for IFR Enroute Low Altitude Charts - U.S. and every two de¬gree by two degree quadrant on IFR Enroute Low Altitude Charts - Alaska. The OROCA is based on the highest known terrain feature or obstruction in each quadrangle, bounded by the ticked lines of latitude/longitude including data 4 NM outside the quadrant. In this example the OROCA represents 12,500 feet.

OROCA is computed just as the Maximum Elevation Figure (MEF) found on Visual Flight Rule (VFR) Charts except that it provides an additional vertical buffer of 1,000 feet in designated non-mountainous areas and a 2,000 foot vertical buffer in designated mountainous areas within the United States. Evaluating the area around the quadrant provides the chart user the same lateral clearance an airway provides should the line of intended flight follow a ticked line of latitude or longitude. OROCA altitudes are not assessed for NAVAID signal coverage, air traffic control surveillance, or communications coverage, and are published for general situational awareness, flight planning, and in-flight contingency use. OROCAs can be found over all land masses and open water areas containing man-made obstructions (such as oil rigs).

**1**2<sup>5</sup>

## MILITARY TRAINING ROUTES (MTRs)

Military Training Routes (MTRs) are routes established for the conduct of low-altitude, high-speed military flight training (generally below 10,000 feet MSL at airspeeds in excess of 250 knots Indicated Air Speed). These routes are depicted in brown on IFR Enroute Low Altitude Charts, and are not shown on inset charts or on IFR Enroute High Altitude Charts. IFR Enroute Low Altitude Charts depict all IFR Military Training Routes (IRs) and VFR Military Training Routes (VRs), except those VRs that are entirely at or below 1,500 feet AGL.

MTRs are identified by designators (IR-107, VR-134) that are shown in brown on the route centerline. Arrows are shown to indicate the direction of flight along the route. The width of the route determines the width of the line that is plotted on the chart:

Route segments with a width of 5 NM or less, both sides of the centerline, are shown by a .02" line.

Route segments with a width greater than 5 NM, either or both sides of the centerline, are shown by a .035" line.

MTRs for particular chart pairs (ex. L1/2, etc.) are alphabetically, then numerically tabulated. The tabulation includes MTR type and unique identification and altitude range.

VR 000 →

IR 000 →

## JET ROUTE SYSTEM (HIGH ALTITUDE ENROUTE CHARTS)

Jet routes are based on VOR or VORTAC NAVAIDs, and are depicted in black with a "J" identifier followed by the route number (e.g., "J12"). In Alaska, Russia and Canada some segments of jet routes are based on LF/MF NAVAIDs.

## AREA NAVIGATION (RNAV) "Q" ROUTE SYSTEM (IFR ENROUTE HIGH ALTITUDE CHARTS)

The FAA has adopted certain amendments to Title 14, Code of Federal Regulations, which paved the way for the development of new area high altitude navigation (RNAV) "Q" routes in the U.S. National Airspace System (NAS). These amendments enable the FAA to take advantage of technological advancements in navigation systems such as the GPS. RNAV "Q" Route MEAs are shown when other than FL 180 MEAs for DME/DME/Inertial Reference Unit (IRU) RNAV aircraft have a "D" suffix.



RNAV routes and associated data are charted in blue."Q" Routes on the IFR Gulf of America charts are shown in black. Magnetic reference courses are shown originating from a waypoint, fix/reporting point, or NAVAID.

Joint Jet/RNAV route identification boxes will be located adjacent to each other with the route charted in black. With the exception of Q-Routes in the Gulf of America, GNSS or DME/DME/IRU RNAV are required, unless otherwise indicated. Q-Routes in Alaska are GNSS Only. Altitude values are stacked highest to lowest.



## **FOREIGN AREAS**

Limited data is depicted in areas outside the U.S. on all appropriate Enroute U.S., Alaska and Pacific High/Low IFR aeronautical charts. The data provided outside the U.S. is for situational awareness and transition planning. Areas outside of the U.S. have been skeletonized and sybmolized in black and/or a black screen applied. This highlights the intent that U.S. charts should only be used for navigation within domestic airspace and charts of other countries should be used within their respective airspace.



## **TERRAIN CONTOURS ON AREA CHARTS**

Based on a recommendation of the National Transportation Safety Board, terrain contours have been added to the Enroute Area Charts and are intended to increase pilots' situational awareness for safe flight over changes in terrain. The following Area Charts portray terrain: Anchorage, Denver, Fairbanks, Juneau, Los Angeles, Nome, Phoenix, San Francisco, Vancouver and Washington.

When terrain rises at least a 1,000 feet above the primary airports' elevation, terrain is charted using shades of brown with brown contour lines and values. The initial contour will be 1,000 or 2,000 feet above the airports' elevation. Subsequent intervals will be 2,000 or 3,000 foot increments.

Contours are supplemented with a representative number of spots elevations and are shown in solid black. The highest elevation on an Area Chart is shown with a larger spot and text.

The following boxed note is added to the affected Area Charts.



FAA Chart Users' Guide - IFR Enroute Terms
# IFR ENROUTE LOW / HIGH ALTITUDE SYMBOLS (U.S., PACIFIC AND ALASKA CHARTS)

# AIRPORTS

Airport Data - Low/High A	ltitude		
Civil	Charts: High/Low	Seaplane - Civil	Charts: Low
Civil And Military	Charts: High/Low	Heliport	Charts: Low
Military	Charts: High/Low	Emergency Use Only	Pacific Only

Facilities in BLUE or GREEN have an approved Instrument Approach Procedure and/or RADAR MINIMA published in either the FAA Terminal Procedures Publication or the DoD FLIPs. Those in BLUE have an Instrument Approach Procedure and/or RADAR MINIMA published at least in the High Altitude DoD FLIPs. Facilities in BROWN do not have a published Instrument Procedure or RADAR MINIMA. Facilities in BLACK are foreign airports.

All IAP Airports are shown on the Low Altitude Charts.

Non-IAP Airports shown on the U.S. Low Altitude Charts have a minimum hard surface runway of 3000'.

Airports shown on the U.S. High Altitude Charts have a minimum hard surface runway of 5000'.

Airports shown on the Alaska High Altitude Charts have a minimum hard or soft surface runway of 4000'.

Associated city names for public airports are shown above or preceding the airport name and city name are the same only the airport name is shown. City names for military and private airports are not shown.

The airport identifier in parentheses follows the airport name or Pvt.

Pvt - Private Use

#### **AIRPORT DATA DEPICTION**

Low Altitude



1. Airport elevation given in feet above or below mean sea level

2. Pvt - Private use, not available to general public

3. A solid line box enclosed the airport name indicates FAR 93 Special Requirements - see Directory/Supplement

4. "NO SVFR" above the airport name indicates FAR 91 fixedwing special VFR flight is prohibited.

5.  $\fbox$  or  $\boxdot$  following the airport identifier indicates Class C or Class D Airspace

High Altitude - U.S.

Minimum Operational Network Airport Designator CITY Airport Name (APT) Airport Identifier 6. Associated city names for public airports are shown above or preceding the airport name. If airport name and city name are the same, only the airport name is shown. The airport identifier in parentheses follows the airport name. City names for military and private airports are not shown.

7. Airport Ident ICAO Location Indicator shown outside contiguous U.S.

8. AFIS Alaska only

High Altitude - Alaska



# **Airports (Continued)**

# LIGHTING CAPABILITY



Compass Locator Beacon







Navigation and Communication Boxes - Common Element	nts
NAVAID STANDARD SERVICE VOLUME (SSV) CLAS- SIFICATIONS	
(VL), (T), etc. indicate SSV. See "NAVAID STANDARD SERVICE VOLUME (SSV) CLASSIFICATIONS" on page 64 or the Chart Supplement for SSV Altitude and Range Boundaries.	(T) (L) (VL) (H) (VH) (DL) (DH)
DISTANCE MEASURING EQUIPMENT	
Facilities that operate in the "Y" mode for DME reception	(Y)
VOICE COMMUNICATIONS VIA NAVAID	
Voice Transmitted	112.6
No Voice Transmitted	<u>111.0</u>
NAVAID SHUTDOWN STATUS	VHF/UHF    LF/MF      ````````````````````````````````````
PART TIME OR ON-REQUEST	
AUTOMATED WEATHER BROADCAST SERVICES	
ASOS/AWOS - Automated Surface Observing Station/Automated Weather Observing Station	VHF/UHF LF/MF
LATITUDE AND LONGITUDE	
Latitude and Longitude coordinates are provided for those NAVAIDs that make up part of a route/airway or a holding pattern. All TACAN facilities will include geographic coordinates.	LOW ENROUTE HIGH ENROUTE N00°00.00' W000°00.00' N00°00.00' W000°00.00'
Navigation and Communication Boxes - Examples	
LOW ENROUTE CHARTS	HIGH ENROUTE CHARTS
VOR R - Receive only 122.1R	VOR
Controlling FSS Name - ANDERSON	W8133.45
(T) - Service Volume	
Receive & Transmit on 122.35122.35(T) - Service VolumeTIFT MYERS (T)Latitude and Longitude112.5 IFM III -Controlling FSS Name - MACONMACON _	

# Navigation And Communication Boxes - Examples (Continued)

	LOW ENROUTE CHARTS	н	GH ENROUTE CHARTS
VOR/DME		VOR/DME	
No Voice Communications (Y) Mode DME	SAWMILL (H)(H) <u>113.75</u> SWB 84(Y) ∷	Off Route (Greyed NAVAID Box and NAVAID)	ПТНАСА 111.8 ПТН (L) (DL) 55
R - Receive only 122.1R Controlling FSS Name - BUFFALC	122.1R ROCKDALE (L)(L) 112.6 RKA 73 +221- N4227.98 W75*14.36 LBUFFALO_	DME in Y Mode	ELMIRA 109.65 ULW (L)(L) 33(Y) M2705.49 119.1
Shadow NAVAID Box FSS Associated with NAVAID	119.1 MIRABEL (L)(L) <u>116.7</u> YMX 114 ΞΗ M553.30 W74725.4	Shadow NAVAID Box FSS Associated with NAVAID	MRABEL 116.7 YMX (L)(L) 114 44553.30 W7472.54
TACAN		TACAN	
TACAN Channels are without voice but not underlined	SANTA ROSA (L) 63 NGS ☴- (133.6) NG736.91 ₩8656.24	Off Route	TYNDALL 64 PAM (H) (133.7) N30'04.44' W85'34.34'
Part Time NAVAID	PENSACOLA (L) ★119 NPA 7≟→-(117.2) N3021.46 ₩87/16.99	Off Route - Part Time NAVAID (Greyed NAVAID Box and NAVAID)	PENSACOLA 119 NPA (L) (117.2) N3021.48 W8718.99
VORTAC	255.4 243.0 122.55 121.5 ALEXANDRIA (H)(H) <u>116.1 AEX 108 :</u> N31'15.40 W92'30.06' [DE RIDDER]		122.55 ALEXANDRIA 116.1 AEX (H)(H) 108 N3175.40 W2730.00'
Shutdown status	BRUNSWICK (L)(L) 第 NHZ 至王 (第 2022) NHZ 52:41 W69755.31*	Off Route (Greyed NAVAID Box and NAVAID)	LDE RIDDER_ HANDLE 114.3 HLL (L) (DL 90
		DME	
DME Channel, Ident, Morse Code VHF Frequency	, MOULTRIE (L) 25 MGR 元∓. (108.8) N3104.94 W8348.25	DME Channel, Ident, VHF Frequency	DUNKIRK 109 DKK (H) (116.2)
NDB		NDB	
A - ASOS/AWOS Available	SILVER BAY		FORT DAVIS 529 FDV N64'29.68' W165'18.91'
Shutdown status	SHEMYA 3032 SYA ::: N52'43.32' E174'03.42'		w 100 10.91
NDB/DME		NDB/DME	
No Voice Communications (Y) Mode DME	122.3 CAPE LISBURNE 385 LUR 20(Y) (108.35) ::::: Ne552.28 W16004.50 LKOTZEBUE	No Voice Communications (Y) Mode DME	CAPE NEWENHAM 385 EHM 18(Y) (108.15) N8539.30' W162'04.42'
Shadow NAVAID Box FSS Associated with NAVAID	123.6 ILIAMNA 411 ILI 91 (114.4) :: N594488 W15454.58	Shadow NAVAID Box FSS Associated with NAVAID Notes: <i>Morse Code is not shown o</i>	ILLAMNA 411 ILI 91 (114.4)

#### Stand Alone Flight Services and Communication Outlets

#### Flight Service Station (FSS)

Shadow NAVAID boxes indicate Flight Service Station (FSS) locations. Frequency 122.2 (Conterminous U.S) and 121.5 and 243.0 (Alaska) are available at many FSSs and are not shown. All other frequencies are shown above the box.

Certain FSSs provide Local Airport Advisory (LAA) on 123.6.

Frequencies transmit and receive except those followed by R and T:

- R Receive Only
- T Transmit Only



# FAA Chart Users' Guide - IFR Enroute Symbology

# Remote Communications Outlet (RCO)

Stand Alone AWOS & ASOS

Thin line NAVAID boxes without frequencies and controlling FSS name indicate no FSS frequencies available. Frequencies positioned above the thin line boxes are remoted to the NAVAID sites. Other frequencies at the controlling FSS named are available, however altitude and terrain may determine their reception.

BOONE AWOS-3PT 118.525 BNW

STAMPEDE PASS ASOS 135.275 SMP

# **AIRSPACE INFORMATION**

# Airway/Route Types

Airway/Route Types Low and High Enroute Airway Data:	VHF/UHF Data is depicted in LF/MF Data is depicted in Br RNAV Route data is depicted	own.
Low Enroute Charts		nroute Charts
Victor Airways	Jet Routes	0000
LF/MF Airway	Atlantic Routes	
RNAV T Route	Bahama Routes	-BROL BROL
GNSS Required		
	RNAV Q Routes	Q00
RNAV TK Helicopter Route    Image: Construction of the second s	CONUS, GNSS or DME/DMI	SS and radar surveillance. Within the E/IRU RNAV required, unless other- RU aircraft require radar surveillance.
Preferred Direction Victor Route	Preferred Direction Jet F	Routes
Unusable Route Segment	Preferred Direction RNA	V Q Routes
Military Training Routes (MTR)	Preferred Direction ATS	Route R000
MTRs 5NM or less both sides of centerline VR-000		nt
MTRs greater than 5NM either IR 000- or both sides of centerline VR 000-		
Arrow indicates direction of route		
See MTR tabulation for altitude range information		
All IR and VR MTRs are shown except those VRs 1500' AGL	at or bleow	
CAUTION: Inset charts do not depict MTRs		
Low and High Enroute Charts		
ATS Route	0 Substitute Route	-0-0-0-0-0-0-
Oceanic Route - A00 - A	All relative and supporting da	ata See NOTAMs or appropriate publication for specific information.

FAA Chart Users' Guide - IFR Enroute Symbology

FIXE VHF/UHF	LF/MF	REPORTING FUNCTION Compulsory Position Reporting	WAYPOINTS RNAV
	$\triangle$	Non-Compulsory Position Reporting	
N25°46.47' W76°16.28'	N29°36.00′ W88°01.00′	<b>Fix or Waypoint Coordinates</b> Fix Coordinates are shown for compulsory, offshore and holding fixes.	N44°25.36' W64°11.00'
		Waypoints Coordinates are shown when waypoint is not part of a RNAV route and when located on or beyond the boundary of the U.S. Continental Control (12 mile limit).	
> <u> </u>		Off-set arrows indicate facility forming a fix - Arrow points away from the VHF/UHF NAVAID - Arrow points towards the LF/MF NAVAID	
∆		Distance Measuring Equipment (DME) Fix    Denotes DME fix (distance same as airway / route mileage)	N/A
	JHF	Distance Measuring Equipment (DME) Fix	RNAV
15)	⇒	Denotes DME fix (encircled mileage shown when not other- wise obvious)	N/A
		Example:	N/A
$\square \xrightarrow{5} \rightarrow \triangle \xrightarrow{1}$	0 <u>15</u> △ —	First segment, 5NM; second segment 10NM; total milage provided in encircled DME arrow.	
VHF/UHF	LF/MF		RNAV
229	149	Total Mileages between Compulsory Reporting Points or NAVAIDs	N/A
		Note: All mileages are in Nautical Miles	
54	125	MILEAGE BETWEEN OTHER FIXES, NAVAIDS AND/OR MILEAGE BREAKDOWN	125
X (AFWOX)	X (MSABI)	Mileage Breakdown or Computer Navigation Fix    (CNF)    Five letter identifier in parentheses indicates CNF with no    ATC function	N/A
000.0 IDT 000	000 ID	FACILITY LOCATOR BOATS	N/A
(000%0 IDT 0000)		Crosshatch indicates Shutdown status of NAVAID	
		RADIAL OUTBOUND FROM A VHF/UHF NAVAID	N/A
	N/A 	All Radials are magnetic.	
		BEARING INBOUND TO AN LF/MF NAVAID	N/A
N/A	000 <del></del>	All Bearings are magnetic.	
N/A	N/A	<b>MAGNETIC REFERENCE BEARING</b> , outbound from a NAVAID or Fix Note: Not shown on joint Victor/RNAV or Jet/RNAV Routes.	000

Airspace Inforr VHF/UHF	nation (Continu LF/MF	ed)	RNAV
LOW CHARTS	S LOW CHARTS	MINIMUM ENROUTE ALTITUDE (MEA) All Altitudes Are MSL Unless Otherwise Noted.	LOW CHARTS
0000	0000		0000G
13000 → 10000 ×8100 18		Directional MEAs	
HIGH CHARTS	6 HIGH CHARTS		HIGH CHARTS
MEA-29000	MEA-FL240	MEAs are shown on IFR High Altitude Charts when MEA is other than 18,000'.	MEA for GNSS RNAV aircraft MEA-24000G
			MEA for DME/DME/IRU RNAV aircraft MEA-24000D
	— — — — CHARTS		
15000 13300G *13300	51 EA GAP 63	MEA is established when there is a gap in navigation signal coverage.	N/A
HIGH O MEA GAP TWISP 65 0 108	CHARTS MEA-24000 <b>J505</b> 91 279		
LOW / HIGH CHARTS	LOW / HIGH CHARTS	Maximum Authorized Altitude (MAA) All Altitudes Are MSL Unless Otherwise Noted.	LOW / HIGH CHARTS
MAA-00000	MAA-00000	MAAs are shown on IFR High Altitude Charts when MAA is other than 45,000'.	MAA-00000
LOW CHARTS	LOW CHARTS	Minimum Obstruction Clearance Altitude (MOCA)	LOW CHARTS
*0000	*0000	All Altitudes Are MSL Unless Otherwise Noted.	*0000
LOW CHARTS	LOW CHARTS	Minimum Turning Altitude (MTA) and Minimum Crossing Altitude (MCA)	LOW CHARTS
X	X	See Low Enroute Chart Example below for examples of both MTAs and MCAs.	X
			N/A
_ → ⊢	_ → ⊢	ALTITUDE CHANGE    MEA, MOCA and/or MAA change at other than NAVAIDs	+ F
LOW / HIGH	LOW / HIGH	CHANGEOVER POINT	N/A
		Changeover Point giving mileage to NAVAIDs (Not shown at midpoint locations.)	
RADDY N47°04.47' W121°30.97'	LARGE N39°17.12' W69°18.07'	HOLDING PATTERNS RNAV Holding Pattern Magnetic Reference Bearing is de- termined by the isogonic value at the waypoint or fix.	
	IOK	Holding Pattern with maximum restriction airspeed 210K applies to altitudes 6000' to and including 14000'. 175K applied to all altitudes. Airspeed depicted is Indicated Airspeed (IAS)	

**Enroute Chart Examples** 



#### Enroute Chart Examples Low Enroute Chart (Continued)





#### Description

#### Multiple MCAs at a NAVAID

V21 and V257 - MCA at DBS of 8600' traveling North V298 - MCA at DBS of 9800' traveling West V343 - MCA at DBS of 8500' traveling North V520 - MCA at DBS of 9000' traveling East V520 - MCA at DBS of 10600' traveling West

#### MCA and MRA at a Fix

MCA at SABAT on V298 of 11,100 traveling East. MRA at SABAT of 10000.

# Example of MOCA and directional MEAs along a Victor Route

Traveling East from DBS, MEA 13,000' the first two segments, 15,000 along third segment.

Traveling West from QUIRT, MEA of 15,000' the first segment, MEA of 10,000 the second segment and MEA of 9,000 the third segment.

MOCA for DBS to SABAT and SABAT to LAMON segments of 8100

#### MCA Example

MCA at OSITY on V330. MCA of 9500' traveling East on V330 from Idaho Falls (IDA) VOR-DME.

#### **Enroute Chart Examples**

#### Low Enroute Chart (Continued)

#### **Reference Number**



#### Description

#### MEA VHF and RNAV Example

MEA for aircraft utilizing VHF NAVAID of 15000' MEA for aircraft utilizing RNAV of 13300'

MOCA of 13300'

#### MCA and MTA Example at a NAVAID

MCA for aircraft traveling West along V520 to cross JAC at 15200' MCA for aircraft traveling West along V330 to cross JAC at 13400'

MTA for aircraft crossing over and turning at JAC:

Aircraft traveling NE on V465 and turning to V330 on a W heading or turning to V520 on a W heading must turn at altitude of 16000' or higher

Aircraft traveling E on V520 and turning to V330 on a W heading must turn at altitude of 14200'

Aircraft traveling E on V330 and turning to V520 on a W heading must turn at altitude of 16000' or higher

Aircraft traveling NW on V328 and turning to V465 on a SW heading must turn at altitude of 15100' or higher.

# **Airspace Information (Continued)**

# **Enroute Chart Examples**

High Enroute Chart



# **Reference Number**



# Description

High RNAV Route with MEA for DME/DME/IRU RNAV Aircraft

MEA of 24,000'

# Preferred Directional Jet Route with Time Restrictions

Jet Route 34 available between 1100 - 0300Z

LO3

EYTEE ←

65 45

DRUZZ

3

MAA-41000 MEA-31000

30

11 41

44

345

285

RAMAY

J30-34

.03002

100-0300z

Q72

30

#### Enroute Chart Examples High Enroute Chart (Continued)

#### **Reference Number**

PETERSBURG

Grant Co

(W99)

104-

1

BENSH

-284

325

O ROD

#### Description

# Preferred Directional Jet Route with Time Restrictions, MAA and MEA

Jet Route 149 available between 1100 - 0300Z MAA - 41,000' MEA - 31,000'



#### Airspace - U.S.

Class A Open Area (White)

High Chart Only

Controlled

Airspace

That airspace from 18,000' MSL to and including FL 600, including the airspace overflying the waters within 12 NM of the coast of the contiguous United States and Alaska and designated offshore areas, excluding Santa Barbara Island, Farallon Island, the airspace south of latitude 25° 04'00" N, the Alaska peninsula west of longitude 160°00'00" W, and the airspace less than 1,500' AGL.

That airspace from 18,000' MSL to and including FL 450, including Santa Barbara Island, Farallon Island, the Alaska peninsula west of longitude 160°00'00" W, and designated offshore areas.



That airspace from the surface to 10,000' MSL (unless otherwise designated) surrounding the nation's busiest airports. Each Class B airspace area is individually tailored and consists of a surface area and two or more layers.

Mode C Area A Solid Blue Outline

Low Chart Only That airspace within 30 NM of the primary airports of Class B airspace and within 10 NM of designated airports. See Chart example above. Mode-C transponder and ADS-B Out equipment is required. (See FAR 91.215)

#### Airspace - U.S. (Continued)



Low Chart Only

Controlled Airspace





That airspace from the surface to 4,000' (unless otherwise designated) above the elevation of selected airports (charted in MSL). The normal radius of the outer limits of Class C airspace is 10NM. Class C airspace is also indicated by the letter C in a box following the airport name.



# **Airspace Information (Continued)**

# AIRSPACE - U.S.

#### **CLASS E**

space

Open Area (White)

Low Chart Only The controlled airspace below 14,500' MSL that is not Class B, C or D.

Federal Airways from 1,200' AGL to but not including 18,000' MSL (unless otherwise specified).

Other designated control areas below 14,500' MSL.

Not Charted

That airspace from 14,500' MSL to but not including 18,000' MSL, including the airspace overflying the waters within 12 NM of the coast of the contiguous United States and Alaska and designated offshore areas, excluding the Alaska peninsula west of longitude 160°00'00" W, and the airspace less than 1,500' AGL.



High and Low Chart

Uncontrolled Airspace



High Altitude

That portion of the airspace from 18,000' MSL and above that has not been designated as Class A airspace.



#### Off Route Obstruction Clearance Altitude (OROCA)

Low Charts Only OROCA is computed similarly to the Maximum Elevation Figure (MEF) found on Visual charts except that it provides an additional vertical buffer of 1,000 feet in designated non-mountainous areas and a 2,000 foot vertical buffer in designated mountainous areas within the United States.

Example: 12,500 feet

**2**<sup>5</sup>

Eureka (88M) 2672 © 42 WOS-AV 118.375 SALT LAKE CITY Ŷ al Lakes Resort Pvt (Ø1MT) 3141 - 50 KALISPELL Glacier Park Int (GPI) D\* 2977 () 90 SEATTLE ASOS 132 625 Lakeside (A) 132.625 Ô SEATTLE SMITH LAKE AKF Ó Carson Fld Pvt (MT53) 3550 - 36 10 ell City 38 16 215 2932 0 36 TAO KILLY 24 Q 15 **JLIB**Y 159 Cabin Creek Landing F (97MT) 3999 - 34 (MTØ3) 3440 - 34 VAILL 9 ~\_\_\_\_^

# Special Flight Rules Area (SFRA)

Low and High Charts SFRA Symbology

WASHINGTON D.C. METROPOLITAN SFRA

Example: Low Chart (Washington Area Chart)





# NAVIGATIONAL AND PROCEDURAL INFORMATION

#### Cruising Altitudes - Low Charts - U.S. Only

IFR outside controlled airspace.

IFR within controlled airspace as assigned by ATC.

ALL courses are magnetic.



VFR above 3000' AGL unless otherwise authorized by ATC.

#### Cruising Altitudes - High Charts - U.S. Only

IFR within controlled airspace as assigned by ATC

All courses are magnetic.



VFR or VFR On Top add 500'

No VFR flights within Class A Airspace above 3000' AGL unless otherwise authorized

#### **RVSM Levels FL290 to FL410** 0°-10:14 FL's FL's 300 290 310 320 340 330 350 360 370 380 390 400

180

No VFR or VFR On Top authorized above FL285 in RVSM airspace.

410



# **Navigational and Procedural Information (Continued)**



FAA Chart Users' Guide - IFR Enroute Symbology

# **U.S. TERMINAL PROCEDURES PUBLICATION**

The U.S. Terminal Procedures Publication (TPPs) includes the Instrument Approach Procedures (IAPs), Departure Procedures (DPs) charts, Standard Terminal Arrival (STAR) charts, Charted Visual Flight Procedure (CVFP) charts, and Airport Diagrams. Also included are Takeoff Minimums, (Obstacle) Departure Procedures, Diverse Vector Area (RADAR Vectors), RADAR and Alternate Minimum textual procedures.

# EXPLANATION OF TPP TERMS AND SYMBOLS

The information and examples in this section are based primarily on the IFR (Instrument Flight Rules) Terminal Procedures Publication (TPP). The publication legends list aeronautical symbols with a brief description of what each symbol depicts. This section will provide more detailed information of some of the symbols and how they are used on TPP charts.

FAA Terminal charts are prepared in accordance with specifications of the Interagency Air Committee (IAC) and their supporting technical groups for the purpose of standardization, which are approved by representatives of the Federal Aviation Administration (FAA), and the Department of Defense (DoD).

The Terminal Procedure Publication is made up of the following charts:

- Instrument Approach Procedure (IAP) Charts
- Airport Diagrams
- Departure Procedures (DP)
- Standard Terminal Arrival (STAR) Charts
- Charted Visual Flight Procedure (CVFP) Charts

# **INSTRUMENT APPROACH PROCEDURE CHART**

The IAPs (charts) are divided into various sections:

Margin Identification Information Briefing Strip Information Planview Missed Approach Information

Profile View Landing Minimums Airport Sketch



#### Margin Identification Information



The margin identification at the top, bottom, and sides of the chart provides information about the airport location, procedure identification, and chart currency. The charts are organized by city first, then airport name and state, with the exception of military charts, which are organized by airport name. Going from the top of the chart, reading from left to right, and going down the chart, Margin Identification Information is organized in the following way.

The hash marks along the top and bottom borders of military Instrument Approach Charts indicate that the procedure was designed using High Altitude criteria contained in FAA Order 8260.3. These procedures are designed to support high performance military aircraft operations and are not intended for civilian use.



#### **Top Margin Information:**

The city and state with which the airport is associated are located on both the top and bottom margins.

At the center of the top margin is the FAA numbering system. This Approach and Landing (AL) number is followed by the organization responsible for the procedure in parentheses, e.g., AL-18 (FAA). Military procedures do no show an AL number, but do show the appropriate authority for the procedure, e.g., (USAF).

WASHINGTON, DC		
WAAS CH <b>56239</b> W34B APP CRS <b>326°</b> Rwy Ldg TDZE Apt Elev	3715 182 192	RNAV (GPS) RWY 34L manassas rgnl/harry p davis fld $(HEF)$

The procedure title is located on both the top and bottom margins. It is derived from the type of navigational facility that is providing the final approach course guidance. The title is abbreviated, e.g. ILS, RNAV, NDB, etc. For airports with parallel runways and simultaneous approach procedures, "L", "R" or "C" follows the runway number to distinguish between left, right, and center runways.

The airport name is shown on both the top and bottom margins below the procedure title. The airport identifier is shown in parentheses following the airport name. Airports outside the contiguous United States will be shown with the FAA designated identifier followed by the ICAO location identifier.

The Date of Latest Revision is shown on the top margin above the procedure title. The Date of Latest Revision identifies the Julian date the chart was last revised for any reason. The first two digits indicate the year, the last three digits indicate the day of the year (001 to 365/6).

WASHINGTON, DC	AL-5326 (FAA)	15344
WAAS    APP CRS    Rwy Ldg    3715      CH 56239    326°    TDZE    182      W34B    APP CRS    App CRS    192	RNAV ( MANASSAS RGNL/HA	GPS) RWY 34L RRY P DAVIS FLD (HEF)
	15211	

# Year|Day of Year

# Side Margin Information:

The side margins show the volume identification, i.e. SW-3, followed by the current issue date and the next issue date, e.g. SW-3, 21 JUL 2016 to 15 SEP 2016.

#### **Bottom Margin Information:**

The FAA Procedure Amendment Number, located on the left bottom margin below the City, State, represents the most current amendment of a given procedure. The Procedure Amendment Effective Date represents the AIRAC cycle date on which the procedure amendment was incorporated into the chart. Updates to the amendment number and effective date represent procedural/criteria revisions to the charted procedure, e.g., course, fix, altitude, minima, etc.

# Example: Original Procedure Date

WASHINGTON, DC	MANA	ASSAS RGNL/HARRY P DAVIS FLD (HEF)
Orig 10DEC15	38°43'N-77°31'W	RNAV (GPS) RWY 34L

T

Example: Amendment Procedure Date

WASHINGTON D.C.	MANA	ASSAS RGNL/HARRY P DAVIS FLD $(\mathrm{HEF})$
Amdt 1B 28MAY15	38°43′N-77°31′W	RNAV (GPS) RWY 16R

The coordinates for the airport reference point are located at the center of the bottom margin.

### **BRIEFING STRIP INFORMATION**

At the top of every TPP is the Briefing Strip that consists of three stacked strips of information immediately above the planview. Information varies depending upon the type of procedure.

WASHINGTON	1, DC	AL-443 (FAA)			15288
LOC/TYPE LD 1799 Chan 36	Briefing Strip 69 0060 Strip 14 Apt Elev 15	IL. RONALD F	<b>S or</b> I Reagan	LOC/DM I WASHINGTO	N NTL (DCA)
Circling A Circling Night I For ino	g NA NE of Rwy 15-33. anding Rwy 4, 15 NA. perative ALSF-2, increase S-LO	Middle Briefing St	ALSF-2	on DCA VOR/D/	ACH: Climb to g left turn to 2100 ME R-325 to GTN 5.9 DME and hold.
ATIS 132.65	POTOMAC APP CC 119.85 COMM 124.2 269.0 (EAS	unications Briefin	ig St	rip con 257.6	CLNC DEL 128.25

#### **Top Briefing Strip**

The top briefing strip contains procedural information in three separate boxes, in the following sequence from left to right:



- Box 1: Primary Procedure Navigation Information: The primary navigation type (VOR, LOC, NDB, RNAV, etc.) with its identifier and frequency/channel. If applicable, WAAS, the WAAS Channel Number, and the WAAS Reference Path indicator are shown stacked top to bottom. If the primary navigation type is GBAS, then the following information is shown, stacked top to bottom: GBAS, CH NNNN, RPI XXXX. If there is not a primary Navigation Box required, the first box is removed.
- Box 2: Final Approach Course Information. The inbound Approach Course (APP CRS) is shown.
- Box 3: Runway Landing Information: Stacked top to bottom, the runway landing distance (Rwy Ldg), the Touchdown Zone Elevation (TDZE), and the Airport Elevation (Apt Elev) are shown. Runway landing distance is determined by comparing the total runway length with the displaced threshold accounted for against the published Declared Distance Landing Distance Available (LDA). The shortest of these lengths, either the published Declared Distance LDA or the total runway length (minus displaced threshold) on the approach end of the runway, will be charted.

Top Briefing Strip Examples:

Ground based NAVAID:

DENVER, COLORADO

LOC/DME I-DZG <u>111.55</u> Chan <b>52</b> (Y)	APP CRS <b>082°</b>	RwyLdg TDZE Apt Elev	12000 5352 5434
--	------------------------	----------------------------	-----------------------



DENVER, COLORADO						
WAAS CH <b>82628</b> <b>W16B</b>	APP CRS <b>173°</b>	Rwy Ldg TDZE Apt Elev	16000 5326 5434			

#### GBAS:

# 16147 RNAV (GPS) Y RWY 16R DENVER INTL (DEN)

AL-285 (FAA)

GBAS		Rwylda	8460
сн <b>22727</b>	APP CRS <b>039°</b>	Rwy Ldg TDZE	10
G04A		Apt Elev	17

No Primary NAVAID box:

DENVER COLORADO

NEWARK NEW IERSEV

APP CRS <b>173º</b>	Rwy Ldg TDZE Apt Elev	12000 5339 5434

Circling Approach:

ROANOKE, VIRGINIA N/A VOR ODR APP CRS Rwy Ldg TDŹE N/A 114.9 236° Apt Elev 1175

Sidestep Procedure:

LOS ANGELES, CALIFORNIA				AL-237 (FAA)	1 (0) 5	
LOC/DME I-OSS <b>108.5</b> Chan <b>22</b>	APP CRS <b>251°</b>	RwyLdg TDZE Apt Elev	24R 8925 120 126	24L 9483 121 126	, in 20, (i) v (j	ILS or LOC RWY 24R LOS ANGELES INTL (LAX)

# **Middle Briefing Strip**

The middle briefing strip may contain information in up to three separate boxes, when available, in the following sequence from left to right:



- Box 1: Notes Box: contains procedure notes, Equipment/Requirements Notes box and Takeoff, Alternate, RA-• DAR, WAAS, and/or Cold Weather indicators (details provided below under Notes Box).
- Box 2: Approach Lighting System Box (when applicable): shows the approach lighting system name and charting icon. Multiple approach lighting systems may be shown for approaches that have straight-in minimums for parallel runways.
- Box 3: Missed Approach Procedure Text Box: The full textual description of the missed approach procedure is • provided here.

<sup>-</sup><sup>-</sup>AA Chart Users' Guide - Terminal Procedures Publication (TPP) - Terms

18256

**GLS RWY 4L** NEWARK LIBERTY INTL (EWR)

16147 RNAV (RNP) Z RWY 17L DENVER INTL (DEN)

ROANOKE-BLACKSBURG RGNL/WOODRUM FLD (ROA)

16203

VOR/DME-A

#### **Notes Box**

#### **Procedure Equipment Requirements Notes Box**

Performance-Based Navigation (PBN) Requirements and ground-based Equipment Requirements are displayed in separate, standardized notes boxes. For procedures with PBN elements, the PBN box contains the procedure's navigation specification(s). If required, specific sensors or infrastructure needed for the navigation solution, additional or advanced functional requirements, and the minimum Required Navigation Performance (RNP) value and any amplifying remarks will also be included. Items listed in this PBN box are REQUIRED. The separate Equipment Requirements Box will list ground-based equipment requirements.



On procedures with both PBN elements and ground-based equipment requirements, the PBN requirements box is listed first.



#### **Remote Altimeter Airport Notes**

Approach minimums are based on the local altimeter setting for that airport unless annotated otherwise. When more than one altimeter source is authorized, and the minima are different, they will be shown by separate lines in the approach minima box or as a note in the briefing strip; e.g., use MHK altimeter setting; when not available use SLN altimeter setting and increase all MDAs 40 feet. The altimeter source location is referenced by the FAA airport identifier. An airport outside the contiguous U.S. will use both the FAA and ICAO identifiers. Until all charts reference the airport identifier, the notes may contain altimeter sources referenced by city name, city and state, or airport name.

#### **Notes Symbols**

Several different symbols may appear within the Notes Box:

- An entry is published in the Takeoff Minimums, (Obstacle) Departure Procedures, and Diverse Vector Area (Radar Vectors) section of the TPP.
- A Non-standard IFR alternate minimums exist. Refer to IFR Alternate Airport Minimums section of the TPP.
- A NA The IAP may not be used as an alternate due to unmonitored facility, absence of weather reporting service, or lack of adequate navigation coverage. IAPs designated with this symbol are not listed in the IFR Alternate Minimums section of the TPP.
- WAAS (Wide Area Augmentation System)
- State Cold Temperature Airport

The negative within a black square box symbol shown in the Notes section below any "A" or "T" Symbol indicates that outages of the WAAS (Wide Area Augmentation System) vertical guidance may occur daily at this location due to initial system limitations. WAAS NOTAMs for vertical outages are not provided for this approach. Use LNAV minima for flight planning at these locations, whether as a destination or alternate. For flight operations at these locations, when the WAAS avionics indicate that LNAV/VNAV or LPV service is available, then vertical guidance may be used to complete the approach using the displayed level of service. Should an outage occur during the procedure, reversion to LNAV minima may be required.

When B-12°C appears in the Notes section below all other symbols it indicates a cold temperature altitude correction is required at that airport when the reported temperature is at or below the published temperature. Advise ATC with altitude correction. Advising ATC with altitude corrections is not required in the final segment. See Aeronautical Information Manual (AIM), Chapter 7, for guidance and additional information. For a complete list of cold temperature airports, see <a href="https://aeronav.faa.gov/d-tpp/Cold\_Temp\_Airports.pdf">https://aeronav.faa.gov/d-tpp/Cold\_Temp\_Airports.pdf</a>.

When "ASR", "PAR" or "ASR/PAR" appear in the Note section immediately below the "T" and "A" symbols it indicates there are published Radar Instrument Approach Minimums. Where radar is approved for approach control service, it is used not only for radar approaches (Airport Surveillance Radar [ASR] and Precision Approach Radar [PAR]) but is also used to provide vectors in conjunction with published non-radar approaches based on radio NAVAIDs (ILS, VOR, NDB, TACAN). Radar vectors can provide course guidance and expedite traffic to the final approach course of any established IAP or to the traffic pattern for a visual approach.

#### Bottom Briefing Strip (Communications Information)

The communications briefing strip contains communication information when available, in separate boxes, listed from left to right in the order that they would be used during arrival with the tower frequency box bolded:

ATIS	APP CON	TOWER	GND CON	CLNC DEL	UNICOM
XXXXX	XXXX XXXX	XXXX XXXX	XXXXX	XXXXX	XXXXX

- ATIS, D-ATIS, AFIS (AK Only) or ASOS/AWOS frequencies (when available, ATIS or AFIS will be the only local weather frequency/s published)
- The primary Approach Control (APP CON) name and frequencies; when the primary approach service is provided by other than Approach Control, e.g. FSS (Radio), Tower, Center, the appropriate air traffic facility call name is provided
- The Control Tower (TOWER) name and frequencies, to include Precision Radar Monitoring (PRM) and frequency
- Ground Control (GND CON) frequencies
- Clearance Delivery (CLNC DEL) frequencies; where a Control Tower does not exist or is part-time, a remoted CLNC DEL may be listed.
- Ground Communications Outlet (GCO) frequency
- Common Traffic Advisory Frequency (CTAF), shown in parentheses when shares a frequency, e.g. UNICOM 122.8 (CTAF)
- UNICOM or AUNICOM frequency
- Controller Pilot Data Link Communication (CPDLC)

Note: Part-time operations will be annotated with a star. Check Chart Supplement for times of operation.

# PLANVIEW

The planview of the IAP charts provides an overhead view of the entire instrument approach procedure.

The data on the planview is shown to scale, unless concentric rings, scale breaks or an inset have been used.

Approach Segments NAVAIDs Area Navigation (RNAV) Waypoints Restrictive Airspeeds Restrictive Altitudes Holding Patterns and Procedure Turns Airports Relief (Terrain Features) Hydrography International Boundary Obstacles (Man-made, Terrain and Vegetation) Special Use Airspace Minimum Safe Altitude Terminal Arrival Areas Helicopter (Copter) Procedures

#### **Approach Segments**

Legend

Feeder Route

The planview includes a graphical depiction of procedure entry through missed approach.



Missed Approach



Complex IAP Example with RF Legs

- **Feeder Routes** (highlighted in blue See Simple IAP Example on previous page) may be used to provide a transition from the enroute structure to the IAF.
- Initial Approach (highlighted in purple in examples above) is the segment between the initial approach fix (IAF) and the intermediate fix (IF) or the point where the aircraft is established on the intermediate course or final approach course.
- Intermediate Approach (highlighted in yellow in examples above) is the segment between the intermediate fix or point and the final approach fix.
- **Final Approach Course** (highlighted in red in the examples above) is the segment between the final approach fix or point and the runway, airport, or missed approach point.
- **Missed Approach** (highlighted in green in the example above) begins at the MAP and continues until the designated fix or waypoint. The missed approach track is shown as a hash marked line in the planview. If any portion of the missed approach procedure track falls outside of the area of the planview it will be shown in a separate box in the planview.
- DME arcs or Radius-to-Fix legs (RF) are shown as smooth arcs from a designated start point to a designated terminus.



• **Visual segment** - Instrument approach procedures, <sup>l</sup>including Copter approach procedures, that terminate or have missed approaches prior to the airport/heliport, and are authorized to proceed visually, will depict the visual flight path by a dashed line symbol from the missed approach point to the airport.

On RNAV charts where the visual track may only apply to a specific line of minima, the visual procedure track line will not be shown in the planview. There will be a note directed to that portion of the procedure track.



Traditional (NAVAID) Approach

RNAV Approach

#### NAVAIDs

NAVAIDs used on ground based charts will show the appropriate symbol accompanied by a data box that contains the facility name, frequency, identifier and Morse code. A NAVAID box with a heavy line indicates the primary NAVAID used for the approach.

NAVAIDs used on GPS based charts show the appropriate symbol identified with the name and identifier.



#### Area Navigation (RNAV) Waypoints

Waypoints are shown with the waypoint symbol accompanied by the five letter identifier. If an RNAV waypoint is collocated with an intersection, DME fix, or NAVAID, the appropriate Intersection, DME fix, or NAVAID symbol will be charted.

On RNAV (RNP) charts, any requirement/capability notes are depicted below the fix/waypoint/NAVAID name. When the required RNP lateral accuracy value for any approach segment other than final approach (e.g. feeder, initial and/or intermediate or missed) are less than standard (RNP 2.00 for feeder, RNP 1.00 for initial and/or intermediate and missed), a note stating the required RNP value may be placed adjacent to the applicable fix at the beginning of the Feeder Route (or annotated in the PBN box). If there is more than one lateral accuracy value within these portions of the procedure, the lowest value is annotated. These notes will take the form "RNP 0.XX, or Min RNP 0.XX" and will be located in close proximity to the relevant fix name (or be identified in the PBN Box).



#### **Localizer Depiction**

The localizer is depicted in the Planview using the following symbol. The size of the charted localizer symbol does not serve as an indication of the service volume.

Right side shading- Front course; Left side shading- Back Course

#### **Restrictive Airspeed**

Restrictive airspeeds are shown paired with their respective fix/facility.

Туре	Description	Example
Recommended Speed	Recommended speed is depicted with no lines above or below it	180K
Minimum Speed	Minimum speed is depicted as a number with a line below it	<u>120K</u>
Maximum Speed	Maximum speed is depicted as a number with a line above it	250K
Mandatory Speed	Mandatory speed is depicted as a number with a line above and below it	175K

#### Altitudes

Restrictive altitudes are shown paired with their respective fix/ facility. Minimum, Maximum, Mandatory and Recommended Altitudes are shown.

Туре	Description	Example
Recommended Altitude	Recommended altitude is depicted with no lines above or below it	3000
Minimum Altitude	Minimum altitude is depicted as a number with a line below it	2500
Maximum Altitude	Maximum altitude is depicted as a number with a line above it	4300
Mandatory Altitude	Mandatory altitude is depicted as a number with a line above and below it	5500
Mandatory Block	Mandatory block altitude is depicted with a minimum and a maximum altitude.	5000
Altitude		3000

Altitudes that are shown along a route are minimum altitudes.



# Holding Patterns and Procedure Turns

Holding Patterns are used for many reasons, including deteriorating weather or high traffic volume. Holding might also be required following a missed approach. Each holding pattern has a fix, a direction to hold from the fix, and an airway, bearing, course, radial, or route on which the aircraft is to hold. These elements, along with the direction of the turns, define the holding pattern. Holding Patterns may not always be depicted to scale.



If a holding pattern has a non-standard speed restriction, it will be depicted by an icon with the limiting air speed shown inside the holding pattern symbol. These elements, along with the direction of the turns, define the holding pattern. If two types of holds are located at the same point, the procedural holding pattern will be shown in-lieu of arrival or missed approach holding patterns. Timing or distance limits for Hold-in-lieu of Procedure Turn Holding Patterns will be shown.

Waypoints designated as a holding fix are shown as fly-by, without the circle around the symbol. However, in the event the holding fix/waypoint is also designated in all other parts of the procedure unrelated to holding with a fly-over function, then the holding fix/waypoint will be charted as a fly-over point.

A procedure turn (PT) is the maneuver prescribed to perform a course reversal to establish the aircraft inbound on an intermediate or final approach course. The procedure turn or hold-in-lieu-of procedure turn is a required maneuver when it is depicted on the approach chart. However, the procedure turn or the hold-in-lieu-of PT is not permitted when the symbol "NoPT" is depicted on the initial segment being flown, when a RADAR VECTOR to the final approach course is provided, or when conducting a timed approach from a holding fix. The procedure turn will be shown in the planview and in the profile of the chart. In the planview, the tip of the procedure turn barb is shown at the procedure turn limit, e.g., 10 NM, 15 NM. Users should be aware that it is possible for there to be a terminal/feeder fix along the procedure track that is not associated with the procedure turn. Fixes associated with the procedure turn are depicted in the profile.



#### Airports

The primary approach airport is shown to scale by a pattern of all the runways. Airports other than the primary approach airport may be shown with an airport pattern and name when in close proximity to the primary airport.



#### **Relief (Terrain Features)**

Terrain is depicted in the planview portion of all IAPs at airports that meet the following criteria:

- If the terrain within the planview exceeds 4,000 feet above the airport elevation, or
- If the terrain within a 6.0 nautical mile radius of the Airport Reference Point (ARP) rises to at least 2,000 feet above the airport elevation.

When an airport meets either of the above criteria, terrain will be charted by gradient tints of brown on all IAPs for that airport. Contour layers will be shown in no more than five brown tints, with consecutively darker tints used for consecutively higher elevation contour layers.


### Hydrography (Water)

Water Depiction is depicted in grey, in the planview portion of IAPs. See previous example. The following hydrographic features are shown:

- Oceans
- Significant rivers and streams
- Significant lakes If only one river or one small lake is involved, not located in the immediate airport vicinity, the hydrographic information requirement may be waived.

#### **International Boundary**

When the planview includes a boundary of another country the International boundaries are shown by a dashed line. International boundaries are identified with country name within the country area.

#### **Obstacles (Man-made, Terrain and Vegetation)**

Obstacles are shown as  $\Lambda$  when they are man-made or vegetation or as a • when they are terrain. The highest obstacle, whether man-made or terrain is depicted with a bolder and larger symbol along with larger elevation font size. Any obstacle that penetrates a slope of 67:1 emanating from any point along the centerline of any runway shall be considered for charting within the area shown to scale. Obstacles specifically identified by the approving authority for charting shall be charted regardless of the 67:1 requirement.

Unverified obstacles shall be indicated by a doubtful accuracy symbol  $\pm$  following the elevation value.



On non-precision approaches, obstacles should be considered when determining where to begin descent from the MDA.



Highest Point - Obstacle





## Special Use Airspace (SUA)

SUAs consists of that airspace wherein activities must be confined because of their nature, or wherein limitations are imposed upon aircraft operations that are not a part of those activities, or both. These are prohibited areas, restricted areas, warning areas, Military Operations Areas (MOAs), and alert areas. SUA that falls within the area of coverage of the instrument approach procedure chart are shown only when designated by the approving authority.



## Air Defense Identification Zone (ADIZ)

ADIZ is an area of airspace in which the identification, location, and control of aircraft is required in the interest of national security. When designated by the approving authority, ADIZ boundaries that fall within the area of coverage of the chart are shown.

#### Minimum Safe Altitude (MSA)

MSAs are published for emergency use on IAP charts. MSAs appear in the planview of all IAPs except on approaches for which a Terminal Arrival Area (TAA) is used. The MSA is based on the primary NAVAID, waypoint, or airport reference point on which the IAP is predicated. The MSA depiction on the approach chart contains the identifier of the NAVAID/waypoint/airport used to determine the MSA altitudes. MSAs are expressed in feet above mean sea level and normally have a 25 NM radius; however, this radius may be expanded to 30 NM if necessary to encompass the airport landing surfaces. Ideally, a single sector altitude is established and depicted on the planview of approach charts; however, when necessary to obtain relief from obstructions, the area may be further sectored and as many as four MSAs established. When established, sectors may be no less than 90° in spread. MSAs provide 1,000 feet clearance over all obstructions but do not necessarily assure acceptable navigation signal coverage.



#### **Terminal Arrival Areas (TAAs)**

The TAA icons will be positioned in the planview relative to their relationship to the procedure. The icon will not have feeder routes, airways, or radar vectors depicted. The TAA provides a transition from the enroute structure to the terminal environment with little required pilot/air traffic control interface for aircraft equipped with Area Navigation (RNAV) systems. A standard TAA has three areas: straight-in, left base, and right base. The arc boundaries of the three areas of the TAA are published portions of the approach. A TAA provides minimum altitudes with standard obstacle clearance when operating within the TAA boundaries. TAAs are primarily used on RNAV approaches but may be used on an ILS approach when RNAV is the sole means for navigation to the IF; however, they are not normally used in areas of heavy concentration of air traffic.



Example of Standard TAA



Example of Non-Standard TAA

## Helicopter (Copter) Procedures

Copter procedures may contain either a visual or a VFR segment. Visual segments are depicted using the dashed line symbol below.

#### Visual Flight Segment

VFR Segments are not depicted with a line, but include the reference bearing and distance information at the endpoint of the VFR Segment, when provided, as shown below.



Example of Copter with VFR Segment (JFK)

When a visual flight path or VFR segment is required from the MAP to the heliport or alighting area, and as necessary for an explicit portrayal, an inset of the MAP area may be provided. This MAP area will depict significant landmark visual features. The procedure track, value and distance to the MAP and the visual segment and value to the landing point shall be shown within this inset. If it is a VFR segment, the reference bearing and distance text will be shown at the landing point.



Example of Copter with Inset

## MISSED APPROACH INFORMATION

Missed approach information is shown in 3 locations on the chart:

- The Middle Briefing Strip The complete textual missed approach instructions are provided at the top of the approach chart in the middle pilot briefing strip.
- The Planview The missed approach track is drawn using a thin, hash marked line with a directional arrow. If any
  portion of the missed approach procedure track is off the chart, the missed approach track shall extend to the
  chart border.



Missed approach holding patterns that lie outside the geographic parameters of the planview and are unable to be shown with a scale break will be shown as a boxed inset. All alternate missed approach holding patterns will be shown in an inset.



 The Profile Box - Missed Approach Icons will be depicted in the upper left or upper right of the profile box. The Missed Approach Icons are intended to provide quick, at a glance intuitive guidance to the pilot, to supplement the textual missed approach instructions in the briefing strip. Space permitting, all textual missed approach instructions will be graphically depicted in sequence. If space does not permit the depiction of all missed approach icons, only the first four icon boxes will be shown.



# PROFILE VIEW

A profile diagram of the instrument approach procedure is shown below the planview. The published descent profile and graphical depiction of the vertical path using those facilities, intersections, fixes, etc. identified in the procedure to the runway are shown. A profile view of the procedure track is shown. The approach track begins toward the top of the primary facility line, unless otherwise dictated by the procedure, and shall descend to where the final approach ends and the missed approach begins.

When a reference mark (\*, \*\*, #, etc.) is shown in the profile, the qualifying footnote is provided within the profile section.







#### **Precision Approaches**

3600

– 1.4 NM

2 NM

GP 3.00° **TCH 52** 

On precision approaches, the glideslope (GS) intercept altitude is illustrated by a zigzag line and an altitude. This is the minimum altitude for GS interception after completion of the procedure turn. Precision approach profiles also depict the GS angle of descent, threshold crossing height (TCH) and GS altitude at the outer marker (OM) or designated fix. The missed approach track is symbolized using the hatched line pattern. Where separate missed approach points exist for precision and non-precision approaches on the same chart, e.g., ILS and LOC, the track will be shown from the precision point only.

2.9 NM

2.5 NM



#### **Non-Precision Approaches**

On non-precision approaches, the final segment begins at the Final Approach Fix (FAF), which is identified with the Maltese cross symbol \*. When no FAF is depicted, the final approach point is the point at which the aircraft is established inbound on the final approach course. Stepdown fixes may also be provided between the FAF and the airport for authorizing a lower minimum descent altitude (MDA) and are depicted with the fix or facility name and a dashed line. Altitude restrictions at stepdown fixes on the final approach on procedures with both precision and non-precision minima are not applicable to precision (ILS, LPV, or LNAV/VNAV) use of the approach. On non-precision only approach procedures, the approach track descends to the MDA or VDP point, thence horizontally to the missed approach point. The missed approach track on non-precision approaches is symbolized using the hatched line pattern and begins at the missed approach point.



## Visual Decent Point (VDP)

The Visual Descent Point (VDP), is shown by a bold letter "V" positioned above the procedure track and centered on the accompanying dashed line. (See example below.) The VDP is a defined point on the final approach course of a non-precision straight-in approach procedure from which normal descent from the MDA to the runway touchdown point may be commenced.



## Vertical Descent Angle (VDA) and Threshold Crossing Heights (TCH)

A VDA and TCH may be published on non-precision approaches. For Copter approach procedures, a Heliport Crossing Height (HCH) will be depicted in place of the TCH. The VDA is strictly advisory and provides a means to establish a stabilized descent to the MDA. The presence of a VDA does not guarantee obstacle protection in the visual segment. If there are obstacles in the visual segment that could cause an aircraft to destabilize the approach between MDA and touchdown, the profile will not show a VDA and will instead show a note that states "Visual Segment-Obstacles".



#### **Visual Flight Path**

Instrument approach procedures, including Copter approach procedures, that terminate or have missed approaches prior to the airport, and are authorized to proceed visual, shall depict the visual segment by the dashed line symbol from the missed approach point to the airport. The note "Fly visual" ("Proceed visually" on Copter procedures) along with the bearing and distance shall be shown leadered to the visual flight path.

RNAV charts sometimes have visual flight for LNAV/VNAV minima that do not start at the missed approach point. An additional note indicating "LNAV/VNAV" will be placed above the note.

Copter approach procedures with a VFR segment from the missed approach point will not depict the VFR segment with a line in the profile. The note similar to "Proceed VFR from MAP" will be shown.



Copter VFR Segment

#### Chart Examples



#### ILS Glide Slope and RNAV Glidepath

A note providing the glide slope (GS) or glidepath (GP) angle and the threshold crossing height (TCH), are positioned in the lower half of the profile box

- GS will be shown on all ILS procedures.
- GP will be shown GLS procedures and all RNAV procedures with a published decision altitude

Threshold Crossing Height (TCH) has been traditionally used in "precision" approaches as the height of the glide slope above threshold. With publication of LNAV/VNAV minimums and RNAV descent angles, including graphically depicted descent profiles, TCH also applies to the height of the "descent angle," or glidepath, at the threshold.

#### 34:1 Surface Clear Stipple Symbol

On RNAV approach charts, a small shaded arrowhead shaped symbol from the end of the VDA to the runway indicates that the 34:1 Obstacle Clearance Surface (OCS) for the visual segment is clear of obstacles. The absence of the symbol indicates that the 34:1 OCS is not clear or a Visual Segment-Obstacles note is indicated on the chart. (See example in VDP Section.)

#### **Secondary Airports**

Airports other than the airport of intended landing will be shown when requested and will be portrayed in the same manner as the primary airport. It will be placed in its approximate location along the final approach course.



## LANDING MINIMUMS

The landing minimums section is positioned directly below the profile. This section gives the pilot the lowest altitude and visibility requirements for the approach. There are two types of landing minimums: Straight-in landing or Circling. Straight-in landing minimums are the MDA and visibility, or DA and visibility, required for a straight-in landing on a specified runway. Circling minimums are the MDA and visibility required for the circle-to-land maneuver.

The minimums for straight-in and circling are located under each aircraft category. When there is not a division line between minimums for each category, the minimums apply to two or more categories.



A second category of straight-in minimums called "sidestep" may be depicted where parallel runways exist.

CATEGORY	А	В	С	D		
S-ILS 24R		320/18 200 (200-1/2)				
S-LOC 24R	40	50/24 340 (400-½)		460/40 340 (400-3⁄4)		
SIDESTEP RWY 24L	58	30/50 459 (500	-1)	580-1½ 459 (500-1½)		

The terms used to describe the minimum approach altitudes differ between precision and nonprecision approaches. Precision approaches use DA and nonprecision approaches use MDA, both expressed in feet MSL. The minimum approach altitudes are also referenced to height above touchdown elevation (HAT) for straight-in approaches, or height above airport (HAA) for circling approaches. The figures listed parenthetically are for military operations and are not used in civil aviation.

The visibility values are shown after the DA or MDA. They are provided in statue miles or runway visual range (RVR). RVR is reported in hundreds of feet. If the visibility is in statute miles, there is an altitude number, hyphen, whole or fractional number, e.g. 530-1. This indicates 530 feet MSL and 1 statute mile of visibility. The RVR value is separated from the minimum altitude with a slash, e.g., 1540/24. This indicates 1540 feet MSL and RVR of 2400 feet. When an RVR value is shown, the comparable statute mile equivalent is shown within the military minimums in parentheses as shown in the examples above. This value is determined from the Comparable Values of RVR and Visibility table located in the TPP Legend.

	Comparable Values of RVR and Visibility							
betw	The following table shall be used for converting RVR to ground or flight visibility. For converting RVR values that fall between listed values, use the next higher RVR value; do not interpolate. For example, when converting 4800 RVR, use 5000 RVR with the resultant visibility of 1 mile.							
	RVR (feet)		· · · ·	Visibility (SM)	RVR (feet)	Visibility (SM)	RVR (feet)	Visibility (SM)
	1600	1/4	2400	1/2	3500	5/8	5500	1
	1800	1/2	2600	1/2	4000	3⁄4	6000	11/4
	2000	1/2	3000	5/8	4500	7⁄8		
	2200	1/2	3200	5/8	5000	1		

When a reference mark (\*, \*\*, #, etc.) is shown on a line of minimums, the qualifying footnote is provided in the notes section.





<sup>41°40′</sup>N-70°31′W ILS or LOC RWY 32

Amdt 1B 21JUL16

### **Circling Minimums**

There was a change to the TERPS criteria in 2012 that affects circling area dimension by expanding the areas to provide improved obstacle protection. To indicate that the new criteria had been applied to a given procedure, a **C** is placed on the circling line of minimums. The new circling tables and explanatory information is located in the Legend of the TPP.

The approaches using standard circling approach areas can be identified by the absence of the **C** on the circling line of minima.

CATEGORY	A	В	С	D	CATEGORY	A	В	С	D
LPV DA	308/24 200 (200-1/2)				, 9120-11/4	9120-1½	9260-3	NA	
LNAV/ DA VNAV	804-2 696 (700-2)			1709 (1800-1½) 1709 (1800-1½) 1849 (1900-3)					
LNAV MDA	800/24 6	92 (700-½)	800-11/2 692 (700-11/2)		Apply Exp	anded Circlind	Approach Ma	aneuverina Ai	rspace Radius
CIRCLING	800-1 6	87 (700-1)         800-2 687 (700-2)         860-2½ 747 (800-2½)		Table		, , , , , , , , , , , , , , , , , , ,			
Apply Standard Circling Approach Maneuvering Radius Table									

# AIRPORT SKETCH

The airport sketch is a depiction of the airport with emphasis on runway pattern and related information, positioned in either the lower left or lower right corner of the chart to aid pilot recognition of the airport from the air and to provide some information to aid on ground navigation of the airport. The runways are drawn to scale and oriented to true north. Runway dimensions (length and width) are shown for all active runways.

Runway(s) are depicted based on what type and construction of the runway.





Taxiways and aprons are shaded grey. Other runway features that may be shown are runway numbers, runway dimensions, runway slope, arresting gear, and displaced threshold.

Other information concerning lighting, airport beacon, obstacles, control tower, NAVAIDs, and helipads may also be shown. The final approach course or an extension of the final approach course will be shown on all IAPs except ILS CAT II, ILS CAT II & III, ILS SA CAT I, ILS SA CAT II, and ILS SA CAT I & II.

## Airport Elevation and Touchdown Zone Elevation

The airport elevation is shown enclosed within a box in the upper left corner of the sketch box and the touchdown zone elevation (TDZE) is shown in the upper right corner of the sketch box. The airport elevation is the highest point of an airport's usable runways measured in feet from mean sea level. The TDZE is the highest elevation in the first 3,000 feet of the landing surface. Circling only approaches will not show a TDZE.

## **Runway Declared Distance Information**

Runway declared distance information when available will be indicated by **D** and is shown to the right of the airport elevation in the sketch box. Declared distances for a runway represent the maximum distances available and suitable for meeting takeoff and landing distance performance requirements.

#### **Runway Lights**

Notes regarding approach lighting systems are shown at the bottom of the sketch box. Runway lights (HIRL) (MIRL) (LIRL) (TDZL)(TDZ/CL) shall be indicated by a note, e.g. HIRL Rwy 9-27. Pilot capability to acitvate the airport lighting is shown using a **0** symbol.

Other approach lighting is shown on the airport sketch as a symbol on the side of the runway where they are actually located. Symbols that are shown in negative indicate pilot-controlled lighting.

Runway centerline lights (CL) are installed on some precision approach runways to facilitate landing under adverse visibility conditions. They are located along the runway centerline and are spaced at 50 foot intervals. Runways with CL are shown in a negative dot pattern through the middle of the solid runway as illustrated in the airport sketch to right.

Runway centerline lights will be indicated by a note only when pilot controlled or when paired with TDZL, e.g., TDZ/CL Rwys 6 and 24.

#### **Time/Distance Table**

When applicable, a Time/Distance Table is provided below the airport sketch. The table provides the distance and time that is required from the final approach fix to the missed approach point for select groundspeeds.

#### **Base Information (Copter Approaches Only)**

Base Information, as required and necessary to identify the MAP area and in the vicinity of the landing area shall be provided. Information shall be limited to and depict significant visual landmark features at and surrounding the MAP area and the heliport/pad of intended landing.

## **AIRPORT DIAGRAMS**

Airport Diagrams are specifically designed to assist in the movement of ground traffic at locations with complex runway/ taxiway configurations. Airport Diagrams are not intended for use in approach and landing or departure operations. An airport diagram assists pilots in identifying their location on the airport, thus reducing requests for "progressive taxi instructions" from controllers.



ELEV (	5434		TDZ	E 53	52	
<ul> <li>▲5</li> <li>√</li> <li>√</li> <li>○</li> <li>082°</li> </ul>	(1) (1) (1) (1) (1) (1) (1) (1)	A3		2000 × 1 0.72 (1.2000) 0.4% UP 0.4% UP		
TDZ/CL Rwys 7, 16L, 16R, 17R, 26, 34L, 34R, 35L, 35R HIRL All Rwys						
FAF to MAP 5 NM						
Knots	60	90	120	150	180	
Min:Sec	5:00	3:20	2:30	2:00	1:40	

#### Airport Diagram Features:

1. Runways

a. Complete with magnetic headings (including magnetic variation and epoch year) and identifiers.

b. Runways under construction shall also be shown.

c. Runway dimensions, displaced thresholds, runway end elevations.

d. Runway surface composition

e. Weight bearing capacity (landing gear configuration or Pavement Classification Number)

f. Land and Hold Short (LAHSO) lines, ILS hold lines, Localizer/Glide Slope Critical Areas.

g. Arresting Gear. To include Engineered Materials Arresting System (EMAS).

- 2. Taxiways, with identifiers. Taxiways under construction shall also be shown.
- 3. Hot Spot locations.
- Parking areas, run-up pads, alert areas, landing pads, "Non-Movement" areas (where pilot is NOT under air traffic control), ramps, aprons and hold pads.
- 5. Turnarounds and run-up areas.
- 6. Stopways, overruns, and blast pads.
- 7. Large tanks, including fueling area.
- 8. Control towers (include tower height).
- 9. Airport beacon.
- 10. Landing direction indicators.
- 11. Lighting.
- 12. Navigational Aids (NAVAIDs).
- 13. Helicopter pads.
- 14. Radar reflectors.
- 15. Highest obstruction within diagram boundary.
- 16. Any building that pilot can taxi to. Other buildings to include terminal/administration and Base operations, fire station, NWS, AFSS, FAA, FSDO, ANG, USCG, FBO.
- 17. Comm Frequencies.

Note: Star when used in the Comm Frequencies indicates part-time status. Check Chart Supplement for times of operation.



#### Runway Construction

Paved or hard surfaced runways consisting of concrete, asphalt, bitumen, or macadam are shown in solid color. Metal surfaced runways are shown using a solid color crosshatch pattern. Ultralight areas, ski landing areas, unpaved or runway other than hard surface, such as sod, clay, gravel, etc., is shown using a solid color dot pattern. Further details regarding runway surface and surface treatment can be found in the Chart Supplement.

Runway construction is depicted as follows:



## **Hot Spots**

Hot Spots (HS) are a runway safety related problem area or intersection on an airport. Typically it is a complex or confusing taxiway/taxiway or taxiway/runway intersection. A confusing condition may be compounded by a miscommunication between a controller and a pilot, and may cause an aircraft separation standard to be compromised. The area may have a history of surface incidents or the potential for surface incidents.

Hot Spots are indicated on the Airport Diagram with a brown open circle or ellipse leadered to a Hot Spot number, e.g., HS 1. The number corresponds to a listing and description on the Hot Spot page in the front the TPP. More information and the location of Hot Spots can be found at <u>http://www.faa.gov/airports/runway\_safety/hotspots/hotspots\_list/</u>.

# **DEPARTURE PROCEDURES (DPs)**

Departure Procedures (DPs) are designed specifically to assist pilots in avoiding obstacles during the climb to the minimum enroute altitude, and/or airports that have civil IFR takeoff minimums other than standard. There are two types of DPs: Obstacle Departure Procedures (ODPs), printed either textually or graphically and Standard Instrument Departures (SIDs), always printed graphically. SIDs are primarily designed for system enhancement and to reduce pilot/controller workload, and require ATC clearance. ODPs provide obstruction clearance via the least onerous route from the terminal area and may be flown without ATC clearance. All DPs provide the pilot with a safe departure from the airport and transition to the enroute structure.

Generally, DP charts are depicted "not to scale" due to the great distances involved on some procedures or route segments. A "to scale" portrayal may be used if readability is assured.

The DP will show the departure routing, including transitions to the appropriate enroute structure. All routes, turns, altitudes, NAVAIDs, facilities forming intersections and fixes, and those facilities terminating the departure route are shown. A textual description of the departure procedure is also provided. For RNAV DPs, the transition text consists of the transition name and associated computer code. On non-RNAV DPs, the transition text will also include the description of all turns, altitudes, radials, bearings and facilities/fixes needed to guide the user from the common departure point to the terminating facility fix. Copter DPs may also include a visual or VFR segment. Visual segments are depicted using the dashed line symbol below.

#### Visual Flight Segment

VFR Segments are not depicted with a line, but include the reference bearing and distance information at the endpoint of the VFR Segment, when provided, as shown below.



 $(\mathsf{H})$ 

Example of Copter with VFR Segment

# STANDARD TERMINAL ARRIVAL (STARs) CHARTS

STARs are pre-planned Instrument Flight Rule (IFR) air traffic control arrival procedures for pilot use in graphic and/or textual form. STARs depict prescribed routes to transition the aircraft from the enroute structure to a fix in the terminal area from which an instrument approach can be conducted. STARs reduce pilot/controller workload and air-ground communications, minimizing error potential in delivery and receipt of clearances.

STAR charts generally shall be depicted 'not to scale' due to the great distances involved on many procedures and route segments. A 'to scale' depiction may be used only if readability is assured.

The STAR will show the arrival routing, including transitions from the appropriate enroute structure. All routes, turns, altitudes, NAVAIDs, facilities forming intersections and fixes, and those facilities/fixes terminating or beginning the arrival route shall be shown in the graphic depiction. A textual description of the arrival procedure is also provided. For RNAV STARs, transition text will consist of the transition name and associated computer code. For non-RNAV STARs, the transition text will also include a description of all turns, altitudes, radials, bearings and facilities/fixes needed to guide the user from the entry point to the common facility/fix.

# CHARTED VISUAL FLIGHT PROCEDURE (CVFP) CHARTS

CVFPs are charted visual approaches established for environmental/noise considerations, and/or when necessary for the safety and efficiency of air traffic operations. The approach charts depict prominent landmarks, courses, and recommended altitudes to specific runways. CVFPs are designed to be used primarily for turbojet aircraft. CVFPs are not instrument approaches and do not have missed approach segments.

CVFPs are named for the primary landmark and the specific runway for which the procedure is developed, such as: RIVER VISUAL RWY 18, STADIUM VISUAL RWY 24. The CVFP charts are divided into planview and notes sections separated by a bar scale in 1 NM increments. The planview of the CVFP includes the portrayal of visual approach procedures information, such as landmarks, NAVAIDs, visual track, hydrography, special use airspace and cultural features, as applicable.

CVFPs originate at or near, and are designed around, prominent visual landmarks and typically do not extend beyond 15 flight path miles from the landing runway. Visual tracks start at a geographical point or landmark where the procedure must be flown visually to the airport. The visual track is indicated by a dashed line. Visual tracks may include the track value, distance and minimum or recommended altitudes.

# **U.S. TERMINAL PROCEDURES PUBLICATION SYMBOLS**

## **GENERAL INFORMATION**

Symbols shown are for the Terminal Procedures Publication (TPP), which includes Standard Terminal Arrival (STARs) Charts, Departure Procedures (DPs), Instrument Approach Procedures (IAP) and Airport Diagrams.

# **PLANVIEW SYMBOLS**

17 APR 2025 to 12 JUN 2025

LEGEND 23334

LEGEND 23334 INSTRUMENT APPROACH	H PROCEDURES (CHARTS)	
PLANVIEW	' SYMBOLS	
ROUTES Procedure Track Feeder Route Missed Approach (Type degree and point of turn optional)	ALTITUDES5500Mandatory Altitude3000Recommended Altitude2500Minimum Altitude5000Mandatory Block4300Maximum Altitude3000Altitude	
Visual Flight Path Minimum Route Altitude — 3100 NoPT to LOM 045° Mileage — (14.2)	INDICATED AIRSPEED <u>175K</u> <u>120K</u> 250K Mandatory Minimum Maximum Recommended Airspeed Airspeed Airspeed	
HOLDING PATTERNS Hold-in-lieu of Procedure Turn HOLD 10000 8000 -090°	RADIO AIDS TO NAVIGATION         110.1       Underline indicates No Voice transmitted on this frequency         VOR       VORTAC       TACAN         VOR/DME       DME	
(IAS) 4 NM Missed Approach 270° 4 NM Missed Approach 4 NM Arrival HOLD <u>8000</u> 090° 	NDB     NDB/DME       Image: Compass locator at Outer Marker)       Marker Beacon       Marker beacons that are not specifically part of	
Holding pattern with maximum restricted airspeed: (175K) applies to all altitudes. (210K) applies to altitudes above 6000' to and including 14000'. Arrival Holding Pattern altitude restrictions will be indicated when they deviate from the adjacent leg. Timing or distance limits for Hold-in-lieu of	the procedure. Localizer Front Course (LOC/LDA) Right side shading- Front course Localizer Back Course Left side shading- Back Course	
Procedure Turn Holding Patterns will be shown. DME fixes may be shown. FIXES/ATC REPORTING REQUIREMENTS A Reporting Point CLGHR INT Intersection	SDF Course SDF Co	
✓     Waypoint       ✓     MAP WP       ✓     (Flyby)       I-LVF     14.9       ✓     MAP WP       ✓     (Flyby)       Ø     MAP WP       ✓     (Flybover)	Primary NAVAID LIMA 114.5 LIM :: Chan 92 Secondary NAVAID LOM AKRON <u>362</u> AK :	
X       Computer Navigation Fix (CNF)-No ATC Function (''x" omitted when it is a MAP)         R-198       Radial line and value         LR-198       Lead Radial         LB-198       Lead Bearing	TACAN or DME NAVAID SCOTT Chan 59 SKE (112.2)	

125



LEGEND 23110



17 APR 2025 to 12 JUN 2025

LEGEND 24361



APR 2025 to 12 JUN 2025

17

# LEGEND 23334 STANDARD TERMINAL ARRIVAL (STAR) CHARTS

17

APR 2025 to 12 JUN 2025

LEGEND

23334

## **DEPARTURE PROCEDURE (DP) CHARTS**



# **AIRPORT DIAGRAM/AIRPORT SKETCH**

AIRPORT DIAGRAM	
Runways	AIRFORT SKETCH
	Helicopter Alighting Areas 🛞 🕂 州 🤼 🕂
Hard Other Than Taxiways, Stopways, Metal	Negative Symbols used to identify Copter Procedures
Surface Hard Surface Parking Overruns, Surface Areas Blast Pads	landing point
	NOTE:
Closed Closed Non- Under Water Runway Surface Movement Construction Runway	Landmark features depicted on Copter Approach inse and sketches are provided for visual reference only.
ARRESTING GEAR: Specific arresting gear systems;	Runway TDZ elevationTDZE 123
e.g., BAK12, MA-1A etc., shown on airport diagrams, not applicable to Civil Pilots. Military Pilots refer to appropriate DOD publications.	Runway Slope ← 0.3% Down0.8% UP → (shown when rounded runway slope is ≥ 0.3%)
↓ 	NOTE:
ARRESTING SYSTEM (EMAS)	Runway Slope measured to midpoint on runways 8000 feet or longer.
	U.S. Navy Optical Landing System (OLS) "OLS" location is shown because of its height of
REFERENCE FEATURES Displaced Threshold	approximately 7 feet and proximity to edge of
Hot Spot	runway may create an obstruction for some types of aircraft.
Runway Holding Position Markings	Approach light symbols are shown in the
Buildings Self-Serve Fuel ##	Flight Information Handbook.
Tanks	Airport diagram scales are variable.
Obstructions∧ Airport Beacon #	True/magnetic North orientation may vary from diagram to diagram
Runway Radar Reflectors Bridges	Coordinate values are shown in 1 or ½ minute
Control Tower #	increments. They are further broken down into 6 second ticks, within each 1 minute increments.
Unlit Lit 🗣	Positional accuracy within ± 600 feet unless otherwis
Landing Tee	noted on the chart.
Tetrahedron	Runway length depicted is the physical length of
# When Control Tower and Rotating Beacon are	the runway (end-to-end, including displaced threshol if any) but excluding areas designated as stopways.
co-located, Beacon symbol will be used and further identified as TWR.	_
## See appropriate Chart Supplement for	A <b>D</b> symbol is shown to indicate runway declared distance information available, see appropriate Char
information.	Supplement for distance information.
Runway Weight Bearing Capacity or Pavement	NOTE: All new and revised airport diagrams are shown refe
Classification Number (PCN)/Pavement Classification Rating (PCR) is shown as a codified expression. Refer	enced to the World Geodetic System (WGS) (noted o
to the appropriate Supplement/Directory for applicable codes e.g., RWY 14-32 PCR 560 R/B/W/T; S-75,	appropriate diagram), and may not be compatible with local coordinates published in DoD FLIP.
D-185, 2D-325, 2D/2D2-1120	(Foreign Only)
	The airport sketch box includes the final approach course or final approach course extended.
Runway Slope FIELD	Displaced Threshold Runway Visual
HS 1 0.7% UP 174	( → → Identification Screen
8	
Runway End ELEV 9000 X 200	
	unway Heàding (Magnetic)
SCO	Movement Area Dimensions (in fee

17 APR 2025 to 12 JUN 2025

LEGEND

## **APPROACH LIGHTING SYSTEM**

#### LEGEND 22195 INSTRUMENT APPROACH PROCEDURES (CHARTS) APPROACH LIGHTING SYSTEM - UNITED STATES

Approach lighting and visual glide slope systems are indicated on the airport sketch by an identifier, e.g., (2), (2), etc.

A dot "•" portrayed with approach lighting letter identifier indicates sequenced flashing lights (F) installed with the approach lighting system e.g., (A). Negative symbology, e.g., (A) (O) indicates Pilot Controlled Lighting (PCL).



LEGEND 22195

## **APPROACH LIGHTING SYSTEM (Continued)**



LEGEND 22195

# REFERENCES

There are several references available from the FAA to aid pilots and other interest parties to learn more about FAA Charts and other aspects of aviation.

Publication		FAA Publication ID
AERONAUTICAL INFORMATION MANCAL	Aeronautical Information Manual (AIM) URL: <u>http://www.faa.gov/air_traffic/publications/</u>	
Arphane Fring Handbook	Airplane Flying Handbook URL: <u>https://www.faa.gov/regulations_policies/handbooks_manuals/aviation/</u> airplane_handbook/	FAA-H-8083-3A
Helicopter Flying Handbook	Helicopter Flying Handbook URL: <u>http://www.faa.gov/regulations_policies/handbooks_manuals/aviation/heli-</u> <u>copter_flying_handbook/</u>	FAA-H-8083-21A
Instrument Procedures Handbook	Instrument Procedures Handbook URL: <u>http://www.faa.gov/regulations_policies/handbooks_manuals/aviation/in-</u> <u>strument_procedures_handbook/</u>	FAA-H-8083-16B
Instrument Rying Handbook	Instrument Flying Handbook URL: <u>https://www.faa.gov/sites/faa.gov/files/regulations_policies/handbooks_</u> <u>manuals/aviation/FAA-H-8083-15B.pdf</u>	FAA-H-8083-15B
Pilot's Handbook of Aeronautical Knowledge	Pilot's Handbook of Aeronautical Knowledge URL: <u>https://www.faa.gov/regulations_policies/handbooks_manuals/aviation/</u> <u>phak/</u>	FAA-H-8083-25B
Received and the search of the	Remote Pilot - Small Unmanned Aircraft Systems Study Guide URL: <u>https://www.faa.gov/sites/faa.gov/files/regulations_policies/handbooks_</u> <u>manuals/aviation/remote_pilot_study_guide.pdf</u>	FAA-G-8082-22

FAA Chart Users' Guide - References

# **ABBREVIATIONS**

## Α

AAF - Army Air Field AAS - Airport Advisory Service AAUP - Attention All Users Page AC - Advisory Circular ADF - Automatic Direction Finder ADIZ - Air Defense Identification Zone ADS - Automatic Dependent Surveillance ADS-B - Automatic Dependent Surveillance-Broadcast Advsry - Advisory AFB - Air Force Base AFIS - Automatic Flight Information Service AFS - Air Force Station **AFSS - Automated Flight Service Station** AGL - Above Ground Level AIM - Aeronautical Information Manual AIRAC - Aeronautical Information Regulation And Control AK - Alaska AL - Approach and Landing ANG - Air National Guard APP - Approach **APP CON - Approach Control** APP CRS - Approach Course Apt - Airport APV - Approaches with Vertical Guidance **ARP** - Airport Reference Point ARTCC - Air Route Traffic Control Center ASDA - Accelerate-Stop Distance Available ASDE-X - Airport Surface Detection Equipment-Model X ASOS - Automated Surface Observing Station ASR - Airport Surveillance Radar ATC - Air Traffic Control ATIS - Automatic Terminal Information Service ATS - Air Traffic Service AUNICOM - Automated Aeronautical Advisory Station AWOS - Automated Weather Observing Station

# В

Baro-VNAV - Barometric Vertical Navigation BS - Broadcast Station

# С

CAC - Caribbean Aeronautical Chart CAT - Category CFA - Controlled Firing Areas CFR - Code of Federal Regulations CH - Channel CL - Runway Centerline Lights CLNC DEL - Clearance Delivery CNF - Computer Navigation Fix COP - Changeover Point CPDLC - Controller Pilot Data Link Communication CRS - Course CT - Control Tower CTAF - Common Traffic Advisory Frequency CVFP - Charted Visual Flight Procedure CZ - Control Zone (Canada)

# D

DA - Decision Altitude DA - Density Altitude D-ATIS - Digital Automatic Terminal Information Service DH - Decision Height DME - Distance Measuring Equipment DND - Department of National Defense (Canada) DoD - Department of Defense DOF - Digital Obstacle File DP - Departure Procedure DT - Daylight Savings Time DVA - Diverse Vector Area

# Ε

E - East EFAS - Enroute Flight Advisory Service EFB - Electronic Flight Bag Elev - Elevation EMAS - Engineered Materials Arresting System

# F

FAA - Federal Aviation Administration FAF - Final Approach Fix FAP - Final Approach Point FAR - Federal Aviation Regulation FBO - Fixed-Based Operator FIR - Flight Information Region FL - Flight Level FLIP - Flight Information Publication FMS - Flight Management System FREQ - Frequency FRZ - Flight Restricted Zone FSDO - Flight Standards District Office FSS - Flight Service Station

# G

GBAS - Ground-Based Augmentation System GCO - Ground Communications Outlet GLS - GBAS Landing System GND - Ground GND CON - Ground Control GNSS - Global Navigation Satellite System GP - Glide Path GPS - Global Positioning System GS - Global Slope GS - Ground Speed

## Η

HAA - Height Above Airport HAR - High Altitude Redesign HAT - Height Above Touchdown HCH - Heliport Crossing Height HF - High Frequency HIRL - High Intensity Runway Lights HS - Hot Spot

## I

IAC - Interagency Air Committee IACC - Interagency Air Cartographic Committee IAF - Initial Approach Fix IAP - Instrument Approach Procedure ICAO - International Civil Aviation Authority IDT - Identifier IF - Intermediate Fix IFR - Instrument Flight Rules ILS - Instrument Landing System IMC - Instrument Meteorological Conditions INS - Inertial Navigation System IR - Instrument Route (Military) IRU - Inertial Reference Unit

# J

JO - Joint Order

# Κ

<sup>-</sup>AA Chart Users' Guide - Abbreviations

KIAS - Knots

# L

LAA - Local Airport Advisory LAAS - Local Area Augmentation System LAHSO - Land and Hold Short LDA - Landing Distance Available LDA - Localizer-type Directional Aid Ldg - Landing LF - Low Frequency LIRL - Low Intensity Runway Lights LNAV - Lateral Navigation LOC - Localizer LOM - Locator Outer Marker LPV - Localizer Performance with Vertical Guidance LRRS - Long Range Radar Station LTP - Landing Threshold Point

## Μ

MAA - Maximum Authorized Altitude MAP - Missed Approach Point MCA - Minimum Crossing Altitude MCAS - Marine Corps Air Station MDA - Minimum Descent Altitude MDH - Minimum Descent Height MEA - Minimum Enroute Altitude
MEF - Maximum Elevation Figure
MF - Medium Frequency
MIA - Minimum IFR Altitude
MIRL - Medium Intensity Runway Lights
MOA - Military Operations Areas
MOCA - Minimum Obstruction Clearance Altitude
MON - Minimum Operational Network
MORA - Minimum Off-Route Altitude
MRA - Minimum Reception Altitude
MSA - Minimum Safe Altitude
MSL - Mean Sea Level
MTA - Minimum Turning Altitude
MTR - Military Training Route
MVA - Minimum Vector Altitude

## Ν

N - North N/A - Not Applicable NA - Not Authorized NAAS - Naval Auxiliary Air Station NAS - Naval Air Station NAS - National Airspace System NAV - Naval Air Facility NAVAID - Navigational Aid (Ground based) NDB - Non-Directional Radiobeacon NextGen - Next Generation Air Transportation System NFDC - National Flight Data Center NFPO - National Flight Procedures Office NM - Nautical Mile NOAA - National Oceanic and Atmospheric Administration NO A/G - No Air-to-Ground Communication NOTAM - Notice to Airmen NoPT - No Procedure Turn NPA - Non-Precision Approach NWS - National Weather Service

# 0

OAT - Outside Air Temperature OBS - Omni Bearing Selector OCA - Ocean Control Area OCS - Obstacle Clearance Surface ODP - Obstacle Departure Procedure OM - Outer Marker OROCA - Off Route Obstruction Clearance Altitude

## Ρ

PA - Precision Approach PAR - Precision Approach Radar PBN - Performance-Based Navigation PRM - Precision Runway Monitor PT - Procedure Turn PTP - Point-to-Point Pvt - Private

## R

R - Radial R - Receive R - Restricted Area (Special Use Airspace) RCO - Remote Communications Outlet RF - Radius-to-Fix RNAV - Area Navigation RNP - Required Navigation Performance RNP AR - Required Navigation Performance Authorization Required ROC - Required Obstacle Clearance RP - Right Pattern RVR - Runway Visual Range RVSM - Reduced Vertical Separation Minimum Rwy - Runway

# S

S - South SAAAR - Special Aircraft and Aircrew Authorization Required SAAR - Special Aircraft and Aircrew Requirements SATNAV - Satellite Navigation SDF - Simplified Directional Facility SER - Start End of Runway SFAR - Special Flight Rules Area SFC - Surface SFRA - Special Flight Rules Area SIAPs - Standard Instrument Approach Procedures SID - Standard Instrument Departure SM - Statute Mile SMAR - Special Military Activity Routes SMGCS - Surface Movement Guidance and Control System SOIA - Simultaneous Offset Instrument Approaches SSV - Standard Service Volume STAR - Standard Terminal Arrival Procedure SUA - Special Use Airspace SVFR - Special Visual Flight Rules

## Т

T - Transmit TA - Travel Advisory TAA - Terminal Arrival Area TAC - Terminal Area Chart **TACAN** - Tactical Air Navigation TAS - True Air Speed TCA - Terminal Control Areas (Canada) TCH - Threshold Crossing Height TDZ - Touchdown Zone TDZE - Touchdown Zone Elevation **TDZL** - Touchdown Zone Lights TDZ/CL - Touchdown Zone/Centerline Lights TERPS - U.S. Standard for Terminal Instrument Procedures **TFR - Temporary Flight Restriction TIBS - Telephone Information Briefing Service** TIS-B - Traffic Information Service - Broadcast

TOC - Top of Climb TOD - Top of Descent TODA - Takeoff Distance Available TOGA - Takeoff/Go Around TORA - Takeoff Runway Available TPP - Terminal Procedures Publication TRSA - Terminal Radar Service Area TWR - Tower

# U

UC - Under Construction UHF - Ultra High Frequency UIR - Upper Information Region UNICOM - Universal Communications U.S. - United States USA - United States Army USAF - United States Air Force USCG - United State Coast Guard UTA - Upper Control Area

# V

VCOA - Visual Climb Over Airport / Airfield VDA - Vertical Descent Angle VDP - Visual Decent Point VFR - Visual Flight Rules VGSI - Visual Glide Slope Indicator VHF - Very High Frequency VMC - Visual Meteorological Conditions VNAV - Vertical Navigation VOR - VHF Omnidirectional Radio Range VORTAC - VHF Omnidirectional Radio Range/Tactical Air Navigation VPA - Vertical Path Angle VR - Visual Route (Military)

# W

W - Warning Area (Special Use Airspace)
W - West
WAAS - Wide-Area Augmentation System
WAC - World Aeronautical Chart
WP - Waypoint
WX CAM - Weather Camera (Alaska)